

PRELIMINARY

ORDNANCE PAMPHLET No. 820

40MM **ANTIAIRCRAFT GUN**

40MM MACHINE GUN MECHANISM
MARK 1 MARK 2 MARK 1, MOD. 1 MARK 2, MOD. 1

40MM GUN BARREL
MARK 1

40MM SIGHT
MARK 3 MARK 4

DESCRIPTION AND OPERATION



OCTOBER 1943

PRELIMINARY

ORDNANCE PAMPHLET No. 820

1

40MM ANTI-AIRCRAFT GUN

40MM Machine Gun Mechanism	Mark 1
40MM Machine Gun Mechanism	Mark 2
40MM Machine Gun Mechanism	Mark 1, Mod. 1
40MM Machine Gun Mechanism	Mark 2, Mod. 1
40MM Gun Barrel	Mark 1
40MM Sight	Mark 3
40MM Sight	Mark 4

DESCRIPTION AND OPERATION




OCTOBER 1943

**NAVY DEPARTMENT
BUREAU OF ORDNANCE
WASHINGTON, D. C.**

ORDNANCE PAMPHLET No. 820
40MM ANTI-AIRCRAFT GUN

October 1943.

1. Ordnance Pamphlet No. 820 provides a description of the construction and operation of the 40MM Machine Gun Mechanism, and descriptions of the gun barrel and sight. It also includes operating instructions and instructions for the care and maintenance of the gun.
2. Ordnance Pamphlet No. 820-A may be used where a less detailed pamphlet is desired.
3. This pamphlet supersedes Ordnance Data No. 3781, preliminary manual for the description and operation of the 40MM anti-aircraft gun. Ordnance Data No. 3781 should be destroyed. Ballistic Data for 40MM Guns are given in Ordnance Pamphlet No. 867.
4. Ordnance Pamphlet No. 820 is UNCLASSIFIED.



Rear Admiral, U. S. N.
Chief of the Bureau of Ordnance

PREFACE

This Ordnance Pamphlet, No. 820, applies
to the following:

**40MM MACHINE GUN MECHANISMS,
MARK 1 AND MARK 2,
MARK 1, MOD. 1 AND MARK 2, MOD. 1**

40MM GUN BARREL, MARK 1

40MM SIGHTS, MARK 3 AND MARK 4

Standard Navy nomenclature is used
herein, and is considered preferable to that
used on drawings and in previous publica-
tions relating to these mechanisms.

York Safe and Lock Co.
York, Pennsylvania

TABLE OF CONTENTS

LIST OF ILLUSTRATIONS	11
-----------------------------	----

CHAPTER I

INTRODUCTION	15
--------------------	----

CHAPTER II

MECHANISM	17
-----------------	----

Part One—Description of Gun Mechanism	17
---	----

Slide Assembly	17
----------------------	----

Trunnion	18
----------------	----

Trigger Mechanism	18
-------------------------	----

Hand Operating Mechanism	19
--------------------------------	----

Top Door	21
----------------	----

Side Door	22
-----------------	----

Rear Door	22
-----------------	----

Bottom Cover	23
--------------------	----

Extractor Release Lever	23
-------------------------------	----

Breech Mechanism Assembly	24
---------------------------------	----

Housing Assembly	24
------------------------	----

Breech Block Assembly	28
-----------------------------	----

Loader Assembly	30
-----------------------	----

Feeding Mechanism	31
-------------------------	----

Rammer Tray	32
-------------------	----

Catch Levers	34
--------------------	----

Cocking Mechanism	34
-------------------------	----

Recoil Cylinder Assembly	37
--------------------------------	----

Piston Rod	37
------------------	----

Throttling Rod	37
----------------------	----

Needle Valve	37
--------------------	----

Recoil Fluid	38
--------------------	----

TABLE OF CONTENTS

MECHANISM (Continued)	
Barrel Assembly	38
Differences Between Mark 1 and Mark 2 Mechanisms	38
Slide Assembly	38
Breech Mechanism Assembly	38
Loader Assembly	38
Recoil Cylinder Assembly	38
Part Two—Operation of Gun Mechanism	41
Firing the First Round	41
Loading	41
Ramming	42
Firing the Round	43
Firing Automatically	44
Action of Breech Mechanism and Loader During Recoil	44
Action of Breech Mechanism and Loader During Counterrecoil	46
Action of the Recoil System	46
CHAPTER III	
BARREL ASSEMBLY	51
40MM Gun Barrel, Mark 1	51
Water Jacket	52
Flash Hider	52
Recoil Spring	52
CHAPTER IV	
SIGHTS	53
Description of Sights	53
40MM Sight, Mark 3	53
40MM Sight, Mark 4	53
Pointer's and Trainer's Sights	53
Use of Sights	54
Alignment of Sights	55
Checking the Alignment	55
Adjustments	56

TABLE OF CONTENTS

CHAPTER V

CYCLIC OPERATION OF THE GUN MECHANISM	57
Feeding the Round	58
Cocking the Rammer	58
Ramming the Round	61
Closing the Breech	61
Firing the Round	62
Ejecting the Case	62

CHAPTER VI

LOADING AND UNLOADING	65
Instructions for Loading	65
Instructions for Unloading	65

CHAPTER VII

CASUALTIES	69
Casualties Which Can Be Corrected Quickly and Easily	69
Clip Placed in Loader Improperly	69
Firing Pedal Not Fully Depressed	69
Other Casualties	69
Live Round Drops Out Into Case Chute	69
Live Round In the Gun or On the Rammer Tray	70
Live Round Still Above Star Wheels	71
Star Wheels Locked	71
Long Recoil	72
Twisted Crankshaft	72

CHAPTER VIII

FUNCTIONAL CHECK-OFF LIST	77
Daily Check	77

TABLE OF CONTENTS

CHAPTER IX

ASSEMBLY AND DISASSEMBLY	78
Barrel Assembly	80
Removal of the Barrel Assembly	80
Installation of the Barrel Assembly	81
Disassembly of the Barrel Assembly	81
Assembly of the Stripped Barrel Assembly	84
Recoil Cylinder Assembly	87
Removal of the Recoil Cylinder Assembly	87
Installation of the Recoil Cylinder Assembly	87
Disassembly of the Recoil Cylinder Assembly	87
Assembly of the Stripped Recoil Cylinder Assembly ..	89
Loader Assembly	92
Removal of the Loader Assembly	92
Installation of the Loader Assembly	94
Removal of the Rammer Tray	94
Installation of the Rammer Tray	95
Disassembly of the Rammer Tray	95
Assembly of the Stripped Rammer Tray	96
Disassembly of the Loader Assembly	97
Assembly of the Stripped Loader Assembly ..	104
Housing Assembly	110
Removal and Disassembly of the Housing Assembly	110
Assembly and Installation of the Housing Assembly	113
Breech Block Assembly	115
Removal and Disassembly of the Breech Block Assembly ...	115
Assembly and Installation of the Breech Block Assembly ...	118
Slide Assembly	120
Removal and Disassembly of the Top Door	120
Assembly and Installation of the Top Door	121
Removal and Disassembly of the Side Door ..	122
Assembly and Installation of the Side Door	123
Removal and Disassembly of the Bottom Cover	123
Assembly and Installation of the Bottom Cover	124
Removal and Disassembly of the Rear Door	124
Assembly and Installation of the Rear Door	124

TABLE OF CONTENTS

ASSEMBLY AND DISASSEMBLY (Continued)

Removal and Disassembly of the Hand Operating Mechanism	126
Assembly and Installation of the Hand Operating Mechanism	127
Removal and Disassembly of the Trigger Mechanism.....	128
Assembly and Installation of the Trigger Mechanism.....	128
Removal of the Extractor Release Lever	130
Installation of the Extractor Release Lever	130
Removal of the Buffer Pad	130
Installation of the Buffer Pad	130
Removal of the Breech Block Locking Bolt Bracket and the Housing Stop	130
Installation of the Housing Stop and the Breech Block Locking Bolt Bracket	130
Sight Assembly	131
Removal of Sight Assembly	131
Installation of Sight Assembly	131
Disassembly of the Sight Assembly	131
Assembly of the Stripped Sight Assembly	132

CHAPTER X

PARTS LIST	133
Barrel Assembly	134
Recoil Cylinder Assembly	135
Loader Assembly	137
Housing Assembly	145
Slide Assembly	148
Sight Assembly	156

CHAPTER XI

APPENDIX	158
Data Sheet	158
Lubrication Instructions	159
Filling the Recoil Cylinder	160
Variations	161

LIST OF ILLUSTRATIONS

1. 40MM Antiaircraft Guns	14
2. Slide Assembly	17
3. Trunnion Diagram	18
4. Trigger Mechanism and Hand Operating Mechanism	19
5. Firing Selector Lever Positions	20
6. Top Door	21
7. Barrel Lock	21
8. Side Door Cam Action	22
9. Rear Door	23
10. Housing—Broken Open View	24
11. Housing—Front View	25
12. Housing—Side View	26
13. Housing—Disassembled	27
14. Safety Plunger	28
15. Breech Block—Disassembled	29
16. Loader Assembly	30
17. Feed Pawls and Stop Pawls	31
18. Loader Assembly—Rear View	32
19. Rammer Tray	33
20. Loader Mechanism	35
21. Sectional View of Recoil Cylinder	37
22. Gun Mechanism Assembly	39
23. Cocking Mechanism	42
24. Breech Closed	43
25. Breech Block—Firing	44
26. Breech Block—Cocking	45
27. Operation of the Recoil Cylinder Assembly	49
28. Barrel Assembly	51
29. Breech End of Barrel	52
30. Sight—Mark 3	53
31. Sight—Mark 4	54

LIST OF ILLUSTRATIONS

32.	Mark 3 Sight Alignment Diagram	55
33.	Mark 4 Sight Alignment Diagram	56
34.	Feeding the Round	59
35.	Cocking the Rammer	59
36.	Ramming the Round	60
37.	Closing the Breech	60
38.	Firing the Round	63
39.	Ejecting the Case	63
40.	Using the Round Releasing Tool	66
41.	Using the Pusher Tool	67
42.	Longitudinal Section of Gun	73
43.	Lateral Sections Through Loader—I	74
44.	Lateral Sections Through Loader—II	75
45.	Lateral Sections Through Housing	76
46.	Special Tools Used in Assembly and Disassembly	78
47.	Recoil Spring Compressor Assembly	82
48.	Recoil Spring Compressor Disassembled	83
49.	Removing the Recoil Cylinder	86
50.	Removing the Needle Valve	88
51.	Recoil Cylinder Disassembled	90
52.	Tightening the Throttling Bushing	91
53.	Rear Door—Open	92
54.	Removing the Tray Bolt	92
55.	Using Loader Lifters	93
56.	Removing the Rammer Tray	94
57.	Tray Pawls	94
58.	Removing Bearing Screw and Rammer Shoe Nut	95
59.	Disassembly of the Rammer Shoe	95
60.	Feed Control Mechanism	97
61.	Removing a Star Wheel Plunger	98
62.	Removing a Star Wheel	99

LIST OF ILLUSTRATIONS

63.	Removing the Feed Pawl Holder	100
64.	Removing the Catch Head	101
65.	Catch Head	101
66.	Removing the Outboard Rammer Cocking Lever	102
67.	Removing the Catch Levers and the Bearing Pin	103
68.	Stop Pawls	106
69.	Feed Pawls	107
70.	Removing the Extractors	110
71.	Removing the Tray Bolt Spring Seat	112
72.	Removing the Barrel Stop	112
73.	Disassembly of the Closing Spring	113
74.	Opening the Side Door	115
75.	Using the Hand Extractor Tool	116
76.	Removing the Breech Block	117
77.	Removing the Firing Spring Cover	118
78.	Removing the Outer Cocking Lever	118
79.	Top Door Assembly	120
80.	Installing the Top Door	121
81.	Removing the Side Door Catch	122
82.	Bottom Cover	123
83.	Removing the Recoil Indicator	125
84.	Removing the Case Deflector Brackets	125
85.	Interior of the Slides	126
86.	Detail of the Interior of the Slide	129

40MM ANTI-AIRCRAFT GUNS




Figure 1

Chapter I

INTRODUCTION

The **40MM Antiaircraft Gun, Figure 1**, consists of the machine gun mechanism, the gun barrel, and the sights. The **40MM Machine Gun Mechanisms** are assembled in pairs. The left mechanism is designated **Mark 1 or Mark 1, Mod. 1**, and the right mechanism is designated **Mark 2 or Mark 2, Mod. 1**. The only differences between the two Marks of mechanisms are those required by the twin assembly. The only difference between the **Mod. 0 and Mod. 1** is that certain parts are not interchangeable between the two. **40MM Gun Barrels, Mark 1**, are used with all mechanisms. The **40MM Sight, Mark 3**, is used on the 40MM Twin Mount; the **40MM Sight, Mark 4**, is used on the 40MM Quadruple Mount.

The design of these mechanisms and barrels is essentially that of the Swedish Bofors 40MM Antiaircraft Gun. The design provides for a rapid fire, recoil operated, automatic mechanism, with a maximum cyclic rate of approximately 160 rounds per minute.

Chapter II

DESCRIPTION

MECHANISM

OPERATION

Part One—Description of Gun Mechanism

The 40MM Machine Gun Mechanism consists of five principal components. They are the **Slide Assembly**, **Breech Mechanism Assembly**, **Loader Assembly**, **Recoil Cylinder Assembly**, and **Barrel Assembly** (excluding barrel).

A. SLIDE ASSEMBLY

The slide, **Figure 2**, is a steel casing which positions and provides working surfaces for other parts of the mechanism. It has a trunnion, trigger




Figure 2

mechanism, hand operating mechanism, top, side, and rear doors, bottom cover and extractor release lever. A Mark 1 and a Mark 2 Mechanism are bolted together and are supported at the trunnions, one on the left side of the Mark 1 Mechanism, and one on the right side of the Mark 2 Mechanism. An elevating arc is attached to the bottom surfaces of the slides.

TRUNNION DIAGRAM




Figure 3

The trunnion on the left is part of the Mark 1 Mechanism, the one on the right is part of the Mark 2 Mechanism.

1. Trunnion

The trunnion, **Figure 3**, contains the firing plunger and crank of the trigger mechanism. The trunnion of the Mark 1 Mechanism is provided with a gear sector to transmit gun elevation to the firing cut-out mechanism of the mount.

2. Trigger Mechanism

The trigger mechanism, **Figure 4**, is on the left side of the Mark 1 Mechanism on the right side of the Mark 2 Mechanism. It is operated by the firing plunger in the trunnion. The trigger is a vertical arm, pivoted near its center, and is located inside and at the rear of the slide, where it contacts and controls the movement of the rammer control spindle arm of the loader. The trigger is operated by a pawl on the firing lever. Motion of the trigger and firing mechanism is limited by the cam on the firing selector lever shaft, as shown in **Figure 5**. When the firing selector lever is at SAFE, motion of the trigger mechanism is prevented by the firing selector cam. When the selector lever is at AUTO FIRE, the trigger can be maintained in the firing

position by the trigger mechanism. When the selector lever is at SINGLE FIRE, motion of the trigger mechanism can be sufficient to permit the pawl to trip and thus release the trigger. The trigger returns to its non-firing position after releasing the trigger catch lever in the loader. Thus in SINGLE FIRE the firing mechanism must be restored to its non-firing position before the trigger can again be operated.






Figure 4

Phantom positions of the rammer control spindle arm show how it contacts the trigger when the loader is placed in the slide. The position of the hand operating lever shaft is shown when the hand operating lever is in the rear catch bracket.



3. Hand Operating Mechanism

The hand operating mechanism, located on the same side of the slide as the trigger mechanism, provides the means for performing manually the operations required to prepare the gun for firing, operations which are otherwise accomplished automatically during recoil and counterrecoil. It



FIRING SELECTOR LEVER POSITIONS



Lever set on SAFE.



Lever set on AUTO FIRE.



Lever set on SINGLE FIRE.

Figure 5

consists of the external hand operating lever and associated internal linkage. The arm on the hand operating lever shaft, **Figure 4**, operates the cocking mechanism of the loader. A projecting lever of the shaft is pinned to the hand operating rod, which engages the toe of the breech mechanism outer crank to cock the breech mechanism. The lever also provides an interlock with the trigger mechanism to prevent firing when the hand operating lever is in the rear catch bracket.

4. Top Door

The top door, **Figure 6**, when open, disengages the barrel lock, **Figure 7**, and rotates the safety catch arm of the housing into position to engage a stop on the slide. This door must be left latched open when the barrel assembly is not in place, to prevent possible rearward movement of the housing.

However, **the top door must always be latched closed before firing**, in order to disengage the safety catch arm from the stop, thus preventing damage to the mechanism.



Figure 6

The top door, when open, disengages the barrel lock.




Figure 7

The barrel lock is shown in both open and closed positions.

SIDE DOOR CAM ACTION




Figure 8

This transparent view shows the action of the cam surface of the side door on the outer crank. The crank is shown at the start and finish of its travel during recoil.

5. Side Door

The side door has a cam surface shown in **Figure 8**, to provide for the rotation of the outer crank of the breech mechanism during recoil.

This door must be opened to remove the breech block, closing spring and cranks from the housing. However, **the side door must always be locked closed before firing**, so that the breech block will be lowered during recoil. Otherwise the breech block will be rammed into the front of the loader causing serious damage.

6. Rear Door

The rear door, **Figure 9**, has an opening to permit the recoil of the rammer tray and ejection of empty cases, and to facilitate removal of live rounds from the tray. It opens to permit removal of the loader and housing assemblies

REAR DOOR




Figure 9

To this door are attached case deflector brackets on which are mounted the case deflector, counterweights, and recoil indicator. This indicator measures the length of recoil, being contacted by the rear of the tray in recoil. It must be reset by hand.

7. Bottom Cover

The bottom cover provides access to the breech mechanism and permits removal of the breech block and associated parts.

8. Extractor Release Lever

The extractor release lever, located in the bottom of the slide, provides for manually releasing the extractors from the breech block.

B. BREECH MECHANISM ASSEMBLY

The breech mechanism assembly consists of a housing assembly, breech block assembly and associated operating parts, and is a recoiling part of the gun mechanism.

1. Housing Assembly

The housing, **Figures 10, 11, and 12**, is a rectangular steel block with projecting bronze-covered bearing strips which ride in corresponding guides in the slide. The housing is provided with an interrupted thread for attaching the breech end of the barrel. The barrel lock is pivoted in the top of the hous-




Figure 10

Broken open housing shows the relationship of the parts of this assembly.

HOUSING—FRONT VIEW




Figure 11

This view of the housing shows the breech block in the closed position.

ing and locks the barrel in the assembled position when the top door is closed. The safety catch arm prevents rearward movement of the housing, when the top door is latched open, by contact against the stop fastened to the slide. A vertical slot is provided for the movement of the breech block. A transverse splined crankshaft keys together the outer crank, two inner

HOUSING—SIDE VIEW




Figure 12

This is the complete assembly for Mark I Mechanism, as it appears from the rear outboard side.

cranks, and the cover of the breech block closing spring. These are shown in **Figure 13**. Cams on the inner cranks operate in slots in the sides of the breech block to open and to close and lock the block in the closed position. Additional cams on the inner cranks operate the outer cocking lever and the sear of the breech block. Extractors, operated by the downward stroke of the

HOUSING DISASSEMBLED




Figure 13

breech block, extract the empty case from the barrel chamber, and lock the block in the open position against the action of the closing spring. The locking is accomplished by the hooks on the extractors engaging abutments on the breech block. The extractors are tripped by a live round catapulted into the chamber, or by manual operation of the extractor release lever. A spring loaded safety plunger, **Figure 14**, moves longitudinally in the housing and contacts a cam on the breech end of the barrel. This plunger moves forward

SAFETY PLUNGER




Figure 14

The safety plunger is shown held back by the cam surface on the breech end of the barrel.

when the barrel is removed, enters a notch in the breech block, and locks the block in the open position. The plunger may be retracted to release the block by the use of a special tool inserted in the top of the housing.

2. Breech Block Assembly

The breech block, **Figure 15**, contains the firing pin and spring, inner and outer cocking levers, and the sear and sear spring. The inner cocking lever holds the firing pin in the cocked position or releases it. The outer cocking lever, which is splined to the inner cocking lever, is acted upon by the cam of the left inner crank to cock the firing pin. In the cocked position, the sear is forced outward by its spring, locking the inner cocking lever. In the firing position, the sear is forced inward by the right inner crank, releasing the inner cocking lever and the firing pin.

BREECH BLOCK-DISASSEMBLED




Figure 15

The disassembled breech block shows all parts of this assembly and their identifying piece numbers. The firing hole bushing is not found in all blocks, as some have the firing hole drilled through the solid face of the block.

C. LOADER ASSEMBLY

The loader assembly, **Figure 16**, consists of feeding, ramming and cocking mechanisms and their associated parts. It is located in the rear of the slide, resting on guides for easy removal, and is locked in place by the rear door.




Figure 16

1. Feeding Mechanism

Live rounds are inserted in the loader in clips of four. The clips are automatically removed by the rear guide and ejected through the clip chute. The side frames include guides which contain the feed pawls and stop pawls, **Figure 17**, for automatically feeding single rounds onto the tray, during the counterrecoil stroke. The feed pawls are attached to a movable holder, which is positioned in the feed rod by a spring loaded plunger. In case of overload, as from a jammed round, the plunger will trip and release the feed




Figure 17

pawl holder as the feed rod completes a stroke. The loader contains two star wheels which are pivoted at the forward ends and positioned at the rear ends by spring loaded plungers, **Figure 18**. The star wheels, **Figure 20**, are locked by catch mechanisms, which are tripped by pawls on the top face of the tray, or released by the hand operating mechanism. When a round is forced through the star wheels by the round above, the case spreads the star wheels sufficiently to pass through as it rotates the star wheels one-quarter turn.




Figure 18

Rear of loader; note transparent treatment of the crosspiece cover to show the star wheel plungers.

2. Rammer Tray

The loader contains the rammer tray, **Figure 19**, which is attached to the rear of the housing and recoils with it. The tray contains the rammer shoe, its levers, and the rammer spring. The rammer shoe, in the cocked position, is so located that the base of the live round, as it is forced through the star

RAMMER TRAY




Figure 19

Below the rammer tray assembly, shown at the top of the picture, are the parts of a disassembled tray.

wheels, will fall into the slots of the rammer levers. The tray supports the live round before the round is catapulted, and provides a guide for the ejected case. Guides in the sides of the tray operate the feed rods during recoil and counterrecoil. The pawls on the top face of the tray unlock the star wheel catch mechanisms during counterrecoil at the instant the feed pawls force a live round through the star wheels onto the tray.

3. Catch Levers

The rammer shoe is latched in the cocked position by one of three levers in the base of the loader. The three levers, **Figure 20**, are:

Center—Tray Catch Lever
Inboard—Loader Catch Lever
Outboard—Trigger Catch Lever

These levers are pivoted on a common shaft and are of varying length so that they release the rammer shoe in the following order: Tray catch lever, loader catch lever, trigger catch lever.

- a. The tray catch lever is operated, through a rocker arm, by a cam on the bottom of the tray, and is in the releasing position whenever the tray is within about one inch of battery position.
- b. The loader catch lever is maintained in the releasing position by a linkage in the rear guide, whenever the loader contains more than one round above the star wheels. Its purpose is to prevent the gun from firing the round on the tray, when there are fewer than two rounds above the star wheels to push another round onto the tray in counterrecoil. This lever is provided to prevent loss of automatic functioning of the mechanism, by latching the rammer shoe in the cocked position, if the loader is supplied with ammunition at a rate less than the rate of fire. This lever releases the rammer shoe automatically upon the insertion of additional clips of ammunition.
- c. The trigger catch lever is controlled by the rammer control spindle, and the arm of the spindle is contacted and controlled by the trigger of the slide assembly. The trigger catch lever is placed in the releasing position whenever the trigger is in the firing position.


4. Cocking Mechanism

The loader contains the cocking mechanism which is operated by the hand operating mechanism of the slide. The cocking mechanism forces the rammer shoe to the rear and thus compresses the rammer spring. At the same time, the cocking mechanism rotates the catch mechanisms so that a round can be forced through the star wheels. Motion of the hand operating lever, beyond the position necessary to latch the rammer shoe, causes the rammer levers to move to the rear end of the slots in the tray. When the rammer levers are in this position, they are spread by the slots, so that a round can be inserted in or removed from the tray through the opening in the rear door.

TRANSPARENT VIEW OF LOADER

Figure 20


Loader mechanism parts are
shown in their proper relationship.



TRANSPARENT VIEW OF LOADER

Figure 20

Important loader mechanism parts are shown in their proper relationship.



D. RECOIL CYLINDER ASSEMBLY

The recoil cylinder assembly, **Figure 21**, provides the necessary retarding force during the recoil and counterrecoil strokes to limit the length of recoil and to control the velocity of counterrecoil. The recoil cylinder is attached under the forepart of the slide, and the piston rod is attached to lugs on the housing.




Figure 21

The recoil cylinder shown in the illustration has been cut open to reveal the relationship of its parts.

1. Piston Rod

The piston rod is attached to the housing and moves in recoil with it. The forward end of the rod is enlarged to form a piston, and contains a throttling bushing which provides an orifice for liquid passing between it and the throttling rod. The inside surface of the piston rod has two grooves, tapered at each end, which control the flow of liquid around the valve seat.

2. Throttling Rod

The throttling rod is attached to the body of the recoil cylinder at the front end. It varies in diameter throughout its length, tapering to its smallest diameter near the front end, thus varying the opening between the rod and the bushing. The rear end of the rod carries the check valve which permits flow of recoil fluid through it only during the recoil stroke.

3. Needle Valve

The needle valve fits into a valve seat inside the throttling rod. By varying the setting of this valve, the velocity of counterrecoil, and consequently, the rate of fire of the gun can be controlled.

4. Recoil Fluid

The fluid used in the recoil cylinder is specified by O.S. 1324. This mixture is approximately sixty percent glycerine and forty percent water, with a small percentage of corrosion inhibiting compound added.

E. BARREL ASSEMBLY

For description of barrel assembly see Chapter III.

F. DIFFERENCES BETWEEN MARK 1 AND MARK 2 MECHANISMS

Since the two mechanisms are bolted together so that they elevate and depress as a unit, certain differences between the Mark 1 and Mark 2 Mechanisms are necessary.

1. Slide Assembly

To permit the gun to be loaded, cocked and fired, each mechanism has its hand operating lever, firing selector lever, trigger mechanism, and firing plunger on the outboard side of the slide. To allow access to the breech mechanism assembly, the side doors are on the outboard side. The extractor release levers are also placed near the outboard side of each slide. The top doors differ in having their catches on the inboard side.

2. Breech Mechanism Assembly

The housings in the Mark 1 and Mark 2 Mechanisms differ in having their breech closing spring assemblies mounted on the inboard side, while the outer cranks, the extractor spindle arms, and safety catch arms are on the outboard side. The breech closing springs differ in the direction of their spirals; the closing spring in the Mark 1 Mechanism is wound so that it increases in diameter in a counter-clockwise direction, when viewed from the convex side of the spring; in the Mark 2 Mechanism, the spring is wound in the opposite direction.

Extractors and breech block assemblies are identical for the two Marks of mechanisms, and are, therefore, interchangeable.


3. Loader Assembly

The differences between the loaders in the Mark 1 and Mark 2 Mechanisms are those which are required to permit the cocking of the rammer and release of the catch mechanisms by the hand operating lever, the operation of the rammer control spindle arm by the trigger, and ejection of the ammunition clips through the outboard side of the slide.

4. Recoil Cylinder Assembly

The only difference between the recoil cylinders in the Mark 1 and Mark 2 Mechanisms is that the fill plug of each is positioned on the outboard side for easy access in filling the recoil cylinders.

Y
other principal com-
gether in the slide.



HOUSING

LOADER

TRAY

SLIDE

INNER CAM SURFACE
OF SIDE DOOR


G ARC
(MENT
75)

COUR
(

GUN MECHANISM ASSEMBLY

Figure 22

The transparent side shows how the other principal components of the mechanism fit together in the slide.



Part Two—Operation of Gun Mechanism

Before automatic operation of the gun mechanism can take place, the gun mechanism must first be cocked and a round fed onto the tray manually. When the trigger catch lever is depressed, the round is rammed into the chamber and fired. The resulting recoil and counterrecoil will now cock the gun mechanism and feed the rounds, thus providing automatic operation.

A. FIRING THE FIRST ROUND

1. Loading

To prepare the mechanism for firing, the hand operating lever is moved to the rear as far as possible and then forward to the rear catch bracket. This movement, **Figure 23**, performs three operations:

It rotates the rammer cocking levers which force the rammer shoe to the cocked position where it is held by the loader catch lever.

It operates the star wheel catch mechanisms, through a linkage and catch release pistons, to permit a quarter turn of the star wheels.

It lowers the breech block, through the hand operating rod, to a position which causes the extractors to lock the block down.

A clip of four rounds is now placed in the loader and pushed smartly home, rotating the star wheels and placing the lowermost round on the rammer tray with its base in the slots of the rammer levers. The clip is automatically detached from the rounds, and ejected through the clip chute of the loader.

These rounds press back the feed control lever, disengaging the loader catch lever from the rammer shoe. The trigger catch lever now holds the rammer shoe until released by the trigger mechanism. The hand operating lever is returned to the forward catch bracket, and the firing selector lever set on AUTO FIRE. The mechanism is now prepared to fire automatically as long as at least two rounds are in the loader above the star wheels.

COCKING MECHANISM




Figure 23

The illustration shows the position of the outer crank, the catch mechanisms, and the rammer cocking levers when the hand operating lever is moved fully to the rear.

2. Ramming

The inward motion of the firing plunger in the trunnion operates the trigger mechanism of the slide and disengages the trigger catch lever from the rammer shoe. The rammer shoe, with the rammer levers and the live round, is forced rapidly forward by the rammer spring. At the end of the rammer stroke, the rammer levers are spread by the slots in the tray, and the live round is released at high velocity and catapulted into the barrel chamber.

BREECH CLOSED




Figure 24

The extractors, caught by the round, have released the breech block, allowing it to be raised to the closed position.

3. Firing the Round

As the round enters the chamber, its base comes into contact with the extractors, pulls them forward, and disengages the extractor hooks from the breech block. The torsion of the breech block closing spring rotates the crankshaft with its attached cranks. The cams on the inner cranks raise the breech block to its closed position, as shown in **Figure 24**. After the breech block is raised, the inner cranks continue to rotate until the cams lock the breech block in its closed position. As the breech block is raised, the pressure of the cam of the left inner crank on the outer cocking lever is released. The inner cocking lever, and thus the firing pin, is now being held by the sear. During the last few degrees of motion of the inner cranks, the lower cam on the right inner crank forces the sear inward, releasing the inner cocking lever, and thus the firing pin. The firing spring then forces the firing pin into

BREECH BLOCK—FIRING




Figure 25

The breech block is shown in the closed position. Transparent treatment of the block shows the relationship of the parts of the assembly.

the primer. This is illustrated in **Figure 25**. The firing pin rotates the freely moving inner and outer cocking levers during its stroke.

B. FIRING AUTOMATICALLY

1. Action of Breech Mechanism and Loader During Recoil

During recoil, the cam on the side door acts on the outer crank to rotate the crankshaft and the inner cranks. The first movement of the inner cranks retracts the firing pin and unlocks the breech block, **Figure 26**. To do this, a

BREECH BLOCK—COCKING




Figure 26

The breech block is cocked during recoil, and the firing pin held back by the inner cocking lever.

cam on the left inner crank depresses the outer cocking lever, and thereby rotates the inner cocking lever, which retracts the firing pin. As the lower arm of the inner cocking lever clears the notch in the sear, the sear spring moves the sear to the right, so that it is held in position to lock the inner cocking lever. In the event of failure of the sear spring, motion of the sear to the right is insured by a cam on the left inner crank. Locking of the inner cocking lever will occur as the breech block is closing, when the outer cocking lever is released by the cam of the left inner crank.

Further rotation of the inner cranks lowers the block into contact with the toes of the extractors, rotating the extractors in the housing. The extractors violently eject the empty case through the housing and loader, between the spread rammer levers, through the rear door, and into the case deflector.

They also lock the breech block in the open position, as shown in **Figure 14**, page 28.

During the recoil movement of the rammer tray, the feed pawls of the loader are raised above the next rounds, which are being held in position by the stop pawls. This motion is produced by the roller on the lower end of the feed rod being moved by the guides on the sides of the tray.

2. Action of Breech Mechanism and Loader During Counterrecoil

During counterrecoil, the breech block closing spring acts to move the breech block to the closed position, but motion of the block is stopped as the breech block is latched open by the hooks on the extractors. Consequently the outer crank is carried clear of the side door cam.

As the tray moves forward during counterrecoil, the pawls on the top surface rotate the catch heads, so that the star wheels can be rotated by the round which is fed between the star wheels and then onto the tray. The rounds in the loader are forced downward by the feed pawls, which in turn are operated by the guides of the tray. As the tray is moving forward, the rammer shoe is latched to the rear by the tray catch lever, in such a position that the base of the next live round above the star wheels will be caught by the slots in the rammer levers as the round is dropped onto the tray. The tray continues forward, and when it is about one inch from battery position, the cam on the bottom of the tray trips the rocker arm, which in turn trips the tray catch lever, releasing the rammer.

The cycle, beginning with the ramming of the live round, will be repeated if the trigger is kept in the firing position, and if the loader contains sufficient rounds, so that the loader catch lever is in the releasing position. If the trigger is kept in the firing position, but the loader contains insufficient rounds for operation of the loader catch lever, firing will cease, but will begin again immediately upon the insertion of additional rounds into the loader.

3. Action of the Recoil System

The recoil system is comprised of the recoil spring and the recoil cylinder. The recoil spring provides in counterrecoil the force necessary to return the gun mechanism to the battery position, cock the rammer, and feed a new round. The recoil cylinder controls the length of recoil and the velocity of counterrecoil.

As the barrel, housing, and tray recoil, the housing carries with it the recoil cylinder piston rod. As the piston rod is drawn to the rear of the recoil

cylinder over the throttling rod, **Figure 27**, liquid is forced from the rear to the front of the piston through the eight holes in the piston and through the throttling bushing. Liquid pressure forces the check valve to the rear, thereby opening the ports in the valve seat. Through these ports liquid now passes to the rear of the valve. Liquid also passes to the rear of the valve around the valve seat and through the tapered grooves inside the piston rod; through the ports in the throttling rod, over the needle valve, and through the seat. These effective flow areas set up a fluid resistance which retards recoil.

Meanwhile, the recoil spring has been placed under greater compression. When recoil ceases, the recoil spring returns the recoiling parts to battery position, and the piston rod moves forward along with the housing.

During counterrecoil, the piston rod moves forward over the throttling rod, and the check valve, under spring action and liquid pressure, masks the ports in the valve seat. Liquid at the rear of the valve seat is forced to the front of the valve seat through the grooves in the piston rod and through the bore in the center of the valve seat. The tapered grooves gradually reduce the flow space as the barrel approaches the battery position until finally no liquid can pass over the valve seat. The flow of liquid from the rear to the front of the seat is now restricted to the bore in the seat, over the needle valve, and through the ports in the throttling rod. Liquid in front of the piston is forced through the throttling bushing and the holes in the piston.

Finally, the front end of the piston enters the recess in the head of the throttling rod. This action forces the liquid between the head and piston through the space between the throttling bushing and the throttling rod. The front taper of the rod reduces the flow space as the barrel approaches the battery position. This action and the tapered grooves inside the piston rod further reduce the speed of counterrecoil.

At the end of counterrecoil, the buffer pad provides a positive stop at battery position for the recoiling parts of the gun mechanism.

The length of recoil is measured by the recoil indicator, attached to the rear door. The indicator is operated by the rear surface of the rammer tray. A length of recoil of approximately 7.2 inches is required to insure automatic operation of the mechanism. Shorter recoil may be insufficient to permit the tray pawls to operate the catch mechanisms of the star wheels, thus preventing feeding. Short recoil may also cause a jam on the tray by causing the star wheels to start to rotate before the ejected case has had time to clear them. The maximum operating length of recoil is about 8.3 inches and is lim-

ited by the design of the throttling rod and bushing in the recoil cylinder. Normal recoil should lie within the above mentioned limits, and will vary somewhat with the elevation of the gun, and with the quantity, specific gravity, and temperature of the recoil fluid.


The velocity in counterrecoil, and thus the rate of fire, is determined by the setting of the needle valve of the recoil cylinder. The setting of this valve has no appreciable effect on the length of recoil. The needle valve is adjustable at the forward end of the recoil cylinder.

OPERATION OF THE RECOIL CYLINDER ASSEMBLY




Figure 27


The top sectional view shows the recoil cylinder when the gun is at battery position, and the other two views show the flow of fluid during the recoil and counter-recoil strokes. The red areas represent fluid under high pressure, while the yellow areas represent fluid under low pressure.







RECOIL →



← COUNTERRECOIL







Chapter III

BARREL ASSEMBLY




Figure 28

A complete barrel assembly is shown at the top of the illustration; below the assembly are shown its individual parts.

The Barrel Assembly, **Figure 28**, includes a 40MM Barrel, Mark 1, its water jacket, a flash hider, and a recoil spring. The barrel assembly is inserted in the cylindrical fore part of the slide and engaged, by a half turn to the right, with mating interrupted threads in the housing. This half turn brings uppermost the barrel interlock slot in the breech end of the barrel, where it receives the barrel lock upon closure of the top door.

1. 40MM Gun Barrel, Mark 1

The breech face of the barrel, **Figure 29**, is also provided with vertical slots to accommodate the extractors, and a cam surface to actuate the breech block safety plunger which is assembled in the housing. The bore is rifled with sixteen grooves having a right hand twist. The rifling is of increasing twist—one turn in 45 calibers at the origin to one turn in 30 calibers at the muzzle.

BREECH END OF BARREL




Figure 29

2. Water Jacket

The water jacket covers the barrel; it is installed over the muzzle end and is retained in place by an attaching nut at the rear end of the barrel. A cooling liquid is circulated through the jacket by a motor driven pump located on the mount.

3. Flash Hider

The flash hider is screwed on the end of the barrel, and is held in place by three set screws. Hexagonal surfaces provide a place for application of the two handled wrench used in installing and removing the barrel.

4. Recoil Spring

The recoil spring is assembled over the fore end of the water jacket. The rear spring seat abuts against a sleeve welded to the outside surface of the water jacket. The recoil spring is retained at its forward end by a spring keeper threaded onto the water jacket. The sleeve on the water jacket provides a bearing surface for the assembly within the cylindrical fore part of the slide.

Chapter IV

SIGHTS

A. DESCRIPTION OF SIGHTS

The sights provide a simple means of giving the necessary lead to allow for target motion during the time of flight of the projectile, and also provide for quick changing of the lead, as the position of the target changes. When the gun is controlled by means of the director, these sights are not used.




Figure 30

Mark 3 sight shown in position on the gun mechanisms of a twin mount.

1. 40MM Sight, Mark 3

The 40MM Sight, Mark 3, **Figure 30**, is used with a pair of 40MM Machine Gun Mechanisms installed in a 40MM Mount, Mark 1 (Twin). The sight arm weldment is bolted to pads on the front end of each of the slides.

2. 40MM Sight, Mark 4

The 40MM Sight, Mark 4, **Figure 31**, is used with two pairs of 40MM Machine Gun Mechanisms installed in a 40MM Mount, Mark 2 (Quad). It differs from the Mark 3 Sight by having two sight arm weldments, each of which is bolted to pads on the front end of the slides on a pair of mechanisms.

3. Pointer's and Trainer's Sights

Each 40MM Sight, Mark 3 or Mark 4, includes a pointer's sight on the left end and a trainer's sight on the right end of the sight arm weldment. The

rear sight of each consists of a vertical post with a peep sight at its upper end. The front sight is a ring type sight consisting of four concentric rings provided with radial strips. Provision is made for vertical and horizontal adjustment of the front sight.




Figure 31

The Mark 4 sight has two separate arm weldments. The pointer's sight of the Mark 4 sight is shown in position on the gun mechanisms of a quad mount.

B. USE OF SIGHTS

The following tables indicate the approximate amounts of lead required at ranges of 1,000 yards and 3,500 yards against targets whose speed components across the line of sight are as listed in the tables.

1,000 Yard Range		3,500 Yard Range	
Sight Ring	Speed Component	Sight Ring	Speed Component
1st (Inner)	75 knots	1st (Inner)	50 knots
2nd	150 knots	2nd	100 knots
3rd	300 knots	3rd	200 knots
4th (Outer)	450 knots	4th (Outer)	300 knots

- c. Insert the two parts of the bore sight.
- d. Train and elevate the gun as required until the bore sight is aligned with the corresponding point " B " of the target.

If the sights are properly adjusted, they will be in line with the black crosses. The alignment of the sights should be checked against both gun barrels.




Figure 33

Mark 4 sight alignment diagram.

2. Adjustments

If the sights are not in line, make the following adjustments:

- a. Loosen the two lock nuts of the front sight until it can be moved horizontally to a point at which the vertical center line of the sight is in line with the rear sight and the black cross on the target.
- b. Tighten the nuts slightly and then turn the adjusting collar until the horizontal center line of the front sight is in line with the rear sight and the black cross on the target.
- c. Tighten the lock nuts securely.

Upon completion of the sight check and adjustment, remove the bore sights, and replace the case deflector brackets.

Chapter V

CYCLIC OPERATION

Cyclic Operation of The Gun Mechanism

In automatic fire, one complete cycle of operation occurs approximately every half second. In each cycle the following basic functions are performed:

A live round is fed onto the tray.

The rammer is cocked.

The round is rammed into the barrel chamber.

The breech is closed.

The round is fired.

The empty case is ejected.



These basic functions are shown step by step in the following diagrams, following a round through the complete cycle from feeding to ejection. In these diagrams, the cool colors (green and blue) are used to indicate the parts of the gun mechanism that move in recoil, while the warm colors (red, orange, and yellow) are used to indicate other moving parts.

A. FEEDING THE ROUND**Figure 34**

The barrel assembly, breech mechanism, and tray are moving forward in counterrecoil. The breech block is held down by the extractors, and the rammer shoe is held back by the tray catch lever. The star wheels are released, the catch heads of the catch mechanisms having been tripped by the rammer tray pawls. The feed pawls, due to the action of the tray guides, are pressing the rounds down. This forces the bottom round between the star wheels and onto the tray.


B. COCKING THE RAMMER**Figure 35**

The barrel assembly, breech mechanism, and tray are still moving forward in counterrecoil and have almost reached battery position. The live round is now on the tray with its base in the slots of the rammer levers. The rammer shoe is being held back by the tray catch lever, and as the tray moves forward, the rammer spring is compressed, cocking the rammer. The trigger catch lever is held down by the trigger mechanism, and the loader catch lever is held down by the rounds in the loader. This leaves only the tray catch lever holding the rammer shoe.




FEEDING THE ROUND

Figure 34




COCKING THE RAMMER

Figure 35




RAMMING THE ROUND



Figure 36



CLOSING THE BREECH

Figure 37





C. RAMMING THE ROUND

Figure 36

The parts that were moving forward in counterrecoil have now reached battery position. The beveled cam on the under side of the tray has ridden over the forward end of the rocker arm, tripping the tray catch lever, thus allowing the rammer shoe and levers to be thrown forward by the action of the rammer spring. As the rammer levers neared the forward limit of their travel, they were spread apart by the cam slots of the tray through which they extend. This allows the round to continue its travel and be thrown into the barrel chamber.

D. CLOSING THE BREECH

Figure 37

The round is completely in the chamber and the closing spring is raising the breech block to the closed position. The breech block is free to rise, because the extractors were unhooked from the block by the base of the round as it was thrown into the chamber. As the block rises, pressure of the cam on the left inner crank is removed from the outer cocking lever. The firing pin is being held back only by the inner cocking lever which is prevented from moving by the sear.

E. FIRING THE ROUND

Figure 38



The breech is completely closed and the round is fired. Firing occurs after the breech is closed, by the action of the cam of the right inner crank upon the sear. The cam forces the sear inward, releasing the inner cocking lever and the firing pin. The firing pin strikes the primer, which explodes the propellant charge of the round.

F. EJECTING THE CASE

Figure 39


The barrel assembly, breech mechanism, and tray are moving rearward as a result of the momentum imparted by the powder pressure at the beginning of recoil. The breech block is in the open position, the outer and inner cranks having been rotated by action of the roller, riding against the cam surface of the side door. The firing pin is cocked by action of the cam of the left inner crank depressing the outer cocking lever. As the breech block descended, it struck the toes of the extractors, ejecting the empty case. The feed pawls, due to the action of the tray guides, are rising in order to feed the next round onto the tray.

A complete cycle has now taken place, and the action repeats itself in automatic fire as long as the loader is supplied with ammunition and the trigger mechanism is held in the firing position.




FIRING THE ROUND

Figure 38



EJECTING THE CASE

Figure 39



Chapter VI

LOADING AND UNLOADING

A. INSTRUCTIONS FOR LOADING

1. Put the firing selector lever on SAFE.
2. Move the hand operating lever all the way to the rear, then latch it in the rear catch bracket.
3. Push a full clip into the loader, so that one round drops onto the rammer tray. When the clip is pushed in far enough to accomplish this, the empty clip will be ejected through the clip chute. Place another full clip in the loader.
4. Move the hand operating lever forward and latch it in the forward catch bracket.
5. See that the feed control thumb lever on the loader rear guide, if provided, is in the position indicated by the red arrow.
6. Place the firing selector lever on AUTO FIRE or SINGLE FIRE as desired.
7.
 - a. Hold the firing pedal of the mount down for automatic fire.
 - b. Press the firing pedal smartly for each shot in single fire.
8. Keep the loader filled.

The loader catch lever will stop operation, with the rammer shoe cocked, when only two rounds remain, one on the tray and one on the star wheels. The gun mechanism is then in condition to resume automatic fire when the loader is refilled, without further manipulation of the hand operating lever.

B. INSTRUCTIONS FOR UNLOADING

1. Place the firing selector lever on SAFE.
2. Elevate the gun to about 30 degrees.
3. Move the hand operating lever all the way to the rear, making sure an assistant catches the live round thus released from the rammer levers, as the round slides through the opening in the rear door.
4. Place the hand operating lever in the rear catch bracket.

5. Install the round releasing tool (298899) in the side frames, **Figure 40**, compressing the feed and stop pawls.
6. Lift out the rounds which have been released. Remove the round releasing tool.
7. Using the pusher tool (298876), **Figure 41**, force the round on the star wheels down on to the rammer tray. Remove the round.
8. Move the hand operating lever fully forward to release the star wheel catch mechanisms, and then latch it in the rear catch bracket.




Figure 40

Using the round releasing tool.

9. Use the pusher tool to force the last round through the star wheels on to the tray. Remove the round as before.
10. When the loader is empty, secure the hand operating lever in the forward catch bracket. Trip the extractors with the extractor release lever to close the breech block.
11. Depress the feed control lever in the rear guide and then release it. This operation will release the rammer shoe from the loader catch lever. Place the firing selector lever at either firing position. Press the firing pedal of the mount smartly to release the rammer shoe from the trigger catch lever.
12. Place the firing selector lever on SAFE.




Figure 41

Using the pusher tool.

Chapter VII

CASUALTIES

In the event of a casualty, the greatest care should be exercised to insure that no actions are taken which can result in injury to personnel or material. It is important to understand that a round in the chamber can be fired unexpectedly even with the firing selector lever on **SAFE**, if for any reason the breech block has failed to close.

A. CASUALTIES WHICH CAN BE CORRECTED QUICKLY AND EASILY

1. Clip Placed in Loader Improperly

The most common loader failure is caused by jammed rounds, resulting from a clip not being passed into the loader properly. To free the rounds thus jammed, insert the round releasing tool (298899) in the loader to hold back the feed and stop pawls. Rounds in the upper part of the loader can then be cleared by hand. Either end of the pusher tool (298876) may be carefully used to pry the jammed rounds loose. Properly loaded rounds should be free enough to be removed by hand. Firing will continue when a new clip is placed in the loader.

2. Firing Pedal Not Fully Depressed

Depress the firing pedal fully. If the gun fires, no further examination is required.

B. OTHER CASUALTIES

1. Live Round Drops Out Into Case Chute

Open the top door.

- α. If the breech block is latched down by the extractors and the empty case has been ejected**, trip the extractor release lever. Closing of the breech block indicates that the breech block closing spring is not broken. Follow the normal loading procedure and continue firing. Casualties of this nature have occurred with no parts damaged and through no fault of the operator.

- b. **If the breech block is in the closed position, and a round is in the chamber,** it is likely that it has failed to extract, but that recoil and counterrecoil were completed, and the ejected live round was rammed against the rear face of the closed breech block. **Examination of the mechanism will probably show that the crankshaft in the housing is twisted or that the extractors are broken.**

2. Live Round In the Gun or On the Rammer Tray

Place the firing selector lever at SAFE. Remove the bottom cover of the slide.

- a. **If the breech block is down, insert the breech block locking bolt, and then open the top door. Never open the top door when it is possible for the gun to fire.** Remove the round through the rear door, and examine the mechanism for damaged parts, such as, broken extractors, twisted crankshaft, broken breech block closing spring, broken rammer rod or spring. Examine the round to determine, if possible, the cause of the trouble. If the gun was at a low angle of elevation when this stoppage occurred, it may have been the same type of casualty as the one described in 1. a. above, when a live round dropped out into the case chute.
- b. **If the breech block is closed, and if examination of the tray** through the opening in the rear door,—without removing the case deflector,—**discloses a live round on the tray,** the case in the chamber is presumably empty, and the casualty should be treated as in paragraph 1. b. above, after removal of the live round.
- c. **If the breech block is closed and a live round is not on the tray or in the case chute, and examination through the bottom opening in the slide shows the base of a case in the gun, a misfire has occurred and the procedure will be governed by the applicable Naval Regulations.** If the breech block is not fully closed for any reason, the firing pin will not be released at all. **In such cases, the breech block may slowly close itself and fire the gun after an apparent misfire,** by wedging action of the breech block finally seating a round in a dirty chamber, by slow action of a gummy breech block, etc. A situation of this kind can usually be determined by examination of the sear in the bottom of the breech block.
- (1) **If the sear is to the left,** that is, the head of the sear is fully in the mating slot, the firing pin has been released and the casualty is probably a misfire.

- (2) **If the sear is to the right**, that is, the head of the sear is not fully in the mating slot and is adjacent to the right inner crank, the firing pin probably has not been released **but the casualty should be treated as a misfire until definite knowledge to the contrary has been determined.** After removal of the round **in accordance with Naval Regulations**, the mechanism should be examined and tested for free operation of all parts.

3. Live Round Still Above Star Wheels

- a. If a round is not on the rammer tray, in the chamber or has not dropped out into the case chute, **feeding through the star wheels may have been prevented by a jammed round in the loader.** In such case the feed pawl safety mechanism has operated. Remove the jammed and other rounds, force or hammer the feed pawls down into their normal positions, and follow the normal loading procedure. Failure to feed may also result from short recoil or a twisted crankshaft in the housing. Either condition may cause slow ejection of the empty case, which will not clear the star wheels in time to permit feeding of the next round.
- b. **If recoil is too short**—less than about seven inches—feeding will be definitely prevented because the catches will not be released. If short recoil is the result of low temperature operation, firing of several rounds may warm the fluid in the recoil cylinder sufficiently to permit automatic operation. Certain of the mechanisms have throttling rods which may prevent sufficient recoil to allow reliable cold weather automatic operation. With such throttling rods, one or two ounces of the fluid in the recoil cylinder should be removed, such that recoil with service charge at approximately zero degrees elevation produces a length of recoil between 7.4 and 7.5 inches. This fluid should be replaced when warmer temperatures are encountered.

C. STAR WHEELS LOCKED

If it is not possible to push a round through the star wheels during the normal loading routine, the star wheels are probably locked by the catch mechanisms. Such a condition will result from a sheared taper pin in the bottom of the loader, in which case motion of the hand operating lever will not release the catch mechanisms. The remedy is to replace the taper pin. However, the gun may be fired normally and safely, before the taper pin is replaced, by loading the first round as follows:

With the hand operating lever all the way to the rear so that the rammer levers are moved to the rear and spread, carefully place a live round on the tray through the rear door opening. Move the hand operating lever slowly forward, at the same time maintaining the round in such a position that the base of the case will be caught in the slots in the rammer levers. The mechanism may then be operated normally.


D. LONG RECOIL

Long recoil will not cause stoppage but may cause excessive stresses in the mechanism. Tests indicate that with the present design of throttling rod and bushing a length of recoil in excess of about 8.3 inches is not practically attainable. However, if this maximum length of recoil is obtained, it is probable that excessive pressures are being developed in the recoil cylinder, and therefore, excessive stresses are being developed elsewhere in the mechanism. **The recoil cylinder should be examined to determine if it has sufficient fluid.**


E. TWISTED CRANKSHAFT

An angular displacement of the housing outer crank of about five degrees, an amount readily detected, from the normal position when the breech block is closed is sufficient to make satisfactory operation doubtful. A twist of approximately eleven degrees will result in no motion of the extractors when the breech block is pulled down. In such case the crankshaft should be replaced. If the extractors are broken, they should be replaced. Even if only one extractor is broken, both should be replaced.

Twisting of the shaft may have developed gradually or may have occurred suddenly during the firing of the last round. If the casualty resulted from a single tight case, it could not have been foreseen. As a precautionary measure, the crankshaft should be examined periodically for this twisted condition. A slow speed of extraction of the empty cartridge case, resulting in a jam on the tray between the ejected case and the next round, is a danger signal that a twisted shaft may be developing. Recoil of less than about 7.2 inches may give the same result.



ELEVATING ARC



TRAY PAWL

FRONT GUIDE

STOP PAWL

BREECH BLOCK

TOP DOOR

BARREL LOCK

BARREL STOP

E

F

M

D

D

M

N

HOUSING

PISTON ROD

E
BOTTOM COVER


F


CLOSING SPRING

CRANKSHAFT

RAMM

ELEVATING ARC






RECOIL
SPRING
KEEPER

LONGITUDINAL SECTION OF GUN

Figure 42


For lateral sections indicated on this
drawing, see Figures 43, 44, 45.






LATERAL SECTIONS
THROUGH
LOADER-I

Figure 43


Sections M-M, N-N, O-O, P-P








SECTION O-O



SECTION P-P




CATCH LEVER
PLUNGER

SECTION P-P


LATERAL SECTIONS THROUGH LOADER-II

Figure 44


Sections R-R, S-S, U-U



SE




SECTION R-R



RAMMER
LEVERS

SECTION S-S





REAR DOOR


SECTION U-U

LATERAL SECTIONS THROUGH HOUSING


Figure 45

Sections A-A, B-B, C-C,
D-D, E-E, F-F, G-G, H-H, L-L







SECTION F-F




SECTION A-A




SECTION G-G
COCKED




SECTION L-L




SECTION A-A




SECTION B-B




SECTION C-C




SECTION D-D



SECTION L-L



SECTION H-H
BARREL IN POSITION



SECTION H-H
BARREL REMOVED

Chapter VIII

FUNCTIONAL CHECK-OFF LIST

A. DAILY CHECK

Breech Mechanism

1. Check operation of the breech block firing mechanism by pulling the hand operating lever about 30 degrees to the rear to cock the firing pin. An audible click should be heard. Let the lever go forward to release the firing pin. This operation should produce another click.
2. Pull the hand operating lever all the way back, then return it to the front catch bracket. Open the top door and inspect the extractors.
3. Trip the extractors with the extractor release lever. The breech block closing spring should cause the breech block to slam up.
4. With the breech block in the closed position, see that the outer crank is not displaced more than five degrees from the normal position. The toe of the crank should normally be parallel to the lower edge of the side door.

Loader

5. Pull the hand operating lever all the way back, then return it to the front catch bracket. See that the rammer shoe is held by the loader catch lever.
6. Place the hand operating lever in the rear catch bracket. Force a round through the star wheels onto the tray. Remove the round.
7. Press the feed control lever. Listen for the click that indicates release of the rammer shoe by the loader catch lever.
8. Put the firing selector lever on AUTO FIRE or SINGLE FIRE. Press the firing pedal to check operation of the rammer.

Chapter IX

ASSEMBLY AND DISASSEMBLY

SPECIAL TOOLS USED IN ASSEMBLY AND DISASSEMBLY




Figure 46

The following list gives the name, Ordnance number and use of all special tools required for assembly and disassembly. These tools are illustrated in **Figure 46**.

298865-1 Spanner Wrench

Used on outside casing (298862) and casing lock nut (298866) of recoil spring compressor.

298868-1	Wrench	Used on closing spring cover (298685-3).
298869-5	Wrench	Used on safety plunger spring seat (298676-1).
298869-6	Wrench	Used on tray bolt (298676-2), tray bolt spring seat (298676-7), firing hole bushing (298682-2), and firing spring cover (298682-1).
298870-1	Spanner Wrench	Used on gland bushing (298739-5), throttling rod (298736-2), and collar (298737-1) of recoil cylinder.
298870-2	Spanner Wrench	Used on recoil cylinder (298730-1).
298871	Side Door Key	For side door lock.
298871-1	Hand Extractor	To extract outer crank and crankshaft.
298872-3	Flash Hider Wrench	Used on flash hider (298663) to remove barrel assembly.
298874-1	Spanner Wrench	Used on throttling bushing (298732-8).
298874-2	Spanner Wrench	Used on rammer spring seat (298793-5).
298874-3	Spanner Wrench	Used on gland nut (298662-2) and attaching nut (298662-1) of water jacket.
298874-4	Spanner Wrench	Used on gun barrel (298652).
298875	Feed Rod Spring Clamp	To compress plunger spring of feed rod holder.
299204-1	Extractor Spindle Tool	To remove extractor spindle (298674-3).
299204-2	Spanner Wrench	Used on recoil spring keeper (298662-4).
299206	Safety Plunger Key	To retract safety plunger.

All piece numbers given in this chapter are for the 40MM Gun Barrel, Mark 1, the 40MM Gun Mechanism, Mark 1, and the 40MM Sights, Marks 3 and 4. Piece numbers for the corresponding parts of the 40MM Gun Mechanism, Mark 2, Mark 1, Mod. 1, and Mark 2, Mod. 1, are listed in the Parts List adjacent to the Mark 1 numbers. Ordnance numbers of individual pieces are not given in the Disassembly sections, but may be found in the corresponding Assembly sections. The piece numbers of all special tools required for either assembly or disassembly are given in both sections.

A. BARREL ASSEMBLY

1. Removal of the Barrel Assembly

- a. Remove the water connection at the water jacket.
 - (1) Turn the hand screw and lift the water connection and its gaskets from its seat on the water jacket.
 - (2) Depress the gun and drain the coolant through the drain on the front end of the water jacket.
- b. Place the gun in the horizontal position and lock the elevation securing device.
- c. Lower the breech block.
 - (1) Disengage the hand operating lever from the front catch bracket and pull it all the way back to lower the breech block, and then return the lever to the rear catch bracket for safety.
This prevents interference of the extractors when the barrel is turned.
- d. Open the top door.
 - (1) Lift the knurled head at the rear of the top door and swing the lever to one side to unlatch the door. Then open the door to release the barrel lock, and latch it open.
- e. Remove the barrel assembly.
 - (1) With two men applying the flash hider wrench (298872-3) to the flash hider and several men to handle the weight of the breech end, rotate the barrel one-half turn to the left to disengage the retaining threads. Remove the barrel assembly by pulling it forward away from the slide.

f. Uncock the gun mechanism.

If the gun is to remain idle for any length of time with the barrel removed, it should be uncocked.

- (1) Place the hand operating lever in the front catch bracket, insert the safety plunger key (299206) in the opening in the top of the housing and turn so as to retract the safety plunger. At the same time, trip the extractor release lever on the bottom of the slide.
- (2) Release the rammer by depressing the feed control lever and operating the firing mechanism.

The top door on the slide should never be closed while the barrel assembly is removed from the gun.

2. Installation of the Barrel Assembly

a. Install the barrel assembly.

- (1) With two men applying the flash hider wrench (298872-3) to the flash hider and several men to handle the weight of the breech end, insert the breech end of the barrel into the forward end of the slide so that the opening for the water connection is on the bottom of the barrel.
- (2) Using care to prevent damage to the threads in the housing or on the barrel, slide the barrel in as far as it will go, rotate the barrel a half turn to the right to engage the threads.

Proper assembly of the barrel with the housing will be indicated when the top door can be closed and latched without requiring force.

- (3) Remove the wrench.

b. Uncock the gun by closing the breech and releasing the rammer.

c. Fill the water jacket with coolant and replace the water connections.

3. Disassembly of the Barrel Assembly

a. Remove the flash hider.

- (1) Remove the three set screws.
- (2) Unscrew the flash hider from the end of the barrel and remove the copper ring.

The flash hider may be removed without disturbing the recoil spring. To remove the recoil spring, the flash hider must first be removed.

b. Remove the recoil spring.

For this purpose, the recoil spring compressor (298860), **Figures 47** and **48**, is required.

- (1) Install the outside casing of the recoil spring compressor.
With the flash hider removed, install the casing (298862) threaded end first, from the front end of the barrel.
- (2) Install the casing lock nut.
Use spanner wrench (298865-1) to install the casing lock nut (298866) and tighten on the threaded end of the outside casing.




Figure 47

Recoil spring compressor assembly used in removing and installing the recoil spring.

- (3) Remove the spring keeper.
Spanner wrenches (298865-1 and 299204-2) are required. Remove the two set screws and unscrew the spring keeper. When the spring keeper is removed, the recoil spring assembly is confined within the outer casing of the recoil spring compressor.
- (4) Remove the spring and the outer casing.
Pull the recoil spring and compressor off the front of the barrel.
- (5) Install the inside casing and the screw assembly.
Install the inside casing (298861) in the nut end of the outside casing (inside the spring), and install the screw assembly (298865) in the opposite end. Using the hand crank

(298867), turn the screw all the way in against spring tension.

- (6) Remove the casing lock nut.

Turn the screw to the right until the spring is slightly compressed and with spanner wrench (298865-1), remove the casing lock nut.




Figure 48

Recoil spring compressor disassembled.

- (7) Release the spring tension.

While holding the outside casing with spanner wrench (298865-1), turn the screw to the left to release the recoil spring.

- (8) Remove the spring from the compressor.

Remove the recoil spring, rear spring seat, and front spring seat from the spring compressor.

Extreme care must be exercised when removing the recoil spring as it is in high compression and if suddenly released may cause serious personal injury.

- c. Remove the water jacket.
 - (1) Using spanner wrench (298874-3), unscrew the gland nut on the front of the water jacket.
 - (2) Remove the two packing rings and the two steel rings.
 - (3) Release the set screw in the attaching nut at the rear end of the water jacket. Turn off the nut, using spanner wrench (298874-3), while holding the barrel with spanner wrench (298874-4).
 - (4) Remove the water jacket and its gasket over the front end of the barrel.
 - (5) Remove the drain plug and washer.

4. Assembly of the Stripped Barrel Assembly

- a. Install the water jacket.
 - (1) Install the gasket (298658-2) and the water jacket (298659-1) over the front end of the barrel.
 - (2) Put on the attaching nut (298662-1). This nut is placed over the breech end of the barrel and screwed onto the water jacket until the screw holes in the nut match the corresponding holes in the water jacket. Use spanner wrench (298874-3) on the attaching nut and spanner wrench (298874-4) on the gun barrel. Put in and tighten the set screw (298662-3).
 - (3) Insert the packing in the front end of the water jacket in the following order: (298658-3), (298658-5), (298658-3), (298658-4).
 - (4) Using spanner wrench (298874-3), screw the gland nut (298662-2) into the front end of the water jacket against the above packing rings.
 - (5) Install the drain plug (298739-7) and washer (298739-4).

- b. Install the recoil spring.

For this operation the recoil spring compressor (298860) is required.

- (1) Place the recoil spring on the inside casing.
 - (a) Stand the inside casing (298861) on end, and place on it the rear spring seat (298666-3), then the recoil spring (298666-1), and finally the front spring seat (298666-2).

- (2) Place the spring under tension.
 - (a) Place the outside casing (298862) over the recoil spring.
 - (b) Insert the screw assembly (298865).
 - (c) While holding the outside casing with spanner wrench (298865-1), use the hand crank (298867) to turn the screw into the inside casing until the spring is compressed far enough to allow the casing lock nut to be attached.
- (3) Remove the inside casing and the screw assembly.
 - (a) Using spanner wrench (298865-1), screw the casing lock nut (298866) on the outside casing.
 - (b) Crank the screw assembly to the left until the recoil spring is retained in the outside casing.
 - (c) Remove the screw assembly and the inside casing.
- (4) Install the spring and casing on the water jacket.


Spanner wrenches (298865-1 and 299204-2) are required.

 - (a) Place the casing and spring, nut end first, over the water jacket.
 - (b) Install the spring keeper (298662-4), and screw it on tightly until the two set screw holes match the corresponding holes in the water jacket.
 - (c) Insert the set screws and draw them up tightly.
- (5) Remove the casing lock nut and the outside casing.
 - (a) With spanner wrench (298865-1), remove the casing lock nut (298866), and take off the outside casing (298862).


c. Install the flash hider.

- (1) Install the copper ring and the flash hider.
 - (a) Place the copper ring (298658-6) over the front end of the barrel. Screw the flash hider (298663-1) tightly against the copper ring, using the flash hider wrench (298872-3), until the set screw holes in the flash hider match those in the barrel.
 - (b) Insert the three set screws (298662-3) and draw them up tightly.


REMOVING THE RECOIL CYLINDER




Loosen the set screw.



Loosen the collar.



Remove the retaining bolts.



Lower the cylinder and remove.

Figure 49

B. RECOIL CYLINDER ASSEMBLY**1. Removal of the Recoil Cylinder Assembly, Figure 49****a.** Loosen the recoil cylinder.

- (1) Elevate the gun to about 50 degrees.
- (2) Loosen the set screw and turn the collar part way off the cylinder, using spanner wrench (298870-1).
- (3) Remove the four retaining bolts and take off the clamp.

b. Remove the assembly.

- (1) Lower the recoil cylinder assembly until it is approximately at right angles to the slide.
- (2) Disengage the securing pin from the housing lugs.

2. Installation of the Recoil Cylinder Assembly**a.** Attach the assembly.

- (1) Elevate the gun to about 50 degrees.
- (2) Holding the recoil cylinder approximately at right angles to the slide, insert the end of the piston rod in the bottom of the slide so that the securing pin is engaged in the lugs on the bottom of the housing.

b. Bolt the recoil cylinder to the gun.

- (1) Bolt the clamp (298727-1) to the pad on the bottom of the slide with the four bolts (1/2"—20 x 1-3/4").
- (2) With spanner wrench (298870-1) turn the collar (298737-1) tight, and insert and tighten the set screw (1/4"—20 x 1/4").

3. Disassembly of the Recoil Cylinder Assembly**a.** Remove the wire seal and the drain and fill plugs.

- (1) Cut the wire seal.
- (2) Remove the plugs and washers. Allow the liquid to drain.

b. Remove the locking plate.

- (1) Remove the retaining bolt, then take off the washers and the locking plate.

REMOVING NEEDLE VALVE




Figure 50

Removing the needle valve after the locking screw and the gland nut have been removed.

- c. Remove the gland nut and the needle valve, **Figure 50**.
 - (1) Remove the locking screw.
 - (2) Remove the gland nut, the needle valve, and the gland rings.
- d. Remove the throttling rod.
 - (1) Hold the recoil cylinder either in a vise or with spanner wrench (298870-2), and unscrew the throttling rod, using spanner wrench (298870-1).
 - (2) Remove the washer.
 - (3) Push in the piston rod and remove the throttling bushing lock screw.
 - (4) Loosen the throttling bushing with spanner wrench (298874-1) and remove the throttling rod assembly.
- e. Remove the securing pin.
 - (1) Remove the securing pin locking screw, and tap out the pin.
- f. Remove the piston rod.
 - (1) Pull the piston rod out of the cylinder.

- g.** Remove the gland bushing, packings, and rings.
 - (1) Use spanner wrench (298870-1) to remove the gland bushing.
 - (2) Remove the rear gland ring, the four chevron packing rings, the center gland ring, the leather packing ring, and the front gland ring.
- h.** Remove the check valve.
 - (1) Tap out the taper pin.
 - (2) Remove the nut, then lift off the spring and the check valve.
- i.** Remove the valve seat and the throttling bushing.
 - (1) Tap out the taper pin.
 - (2) Unscrew the valve seat from the throttling rod, and remove the throttling bushing.

4. Assembly of the Stripped Recoil Cylinder Assembly, Figure 51.

- a.** Assemble the valve seat on the throttling rod.
 - (1) Place the throttling bushing (298732-8) over the throttling rod (298736-2), holding the end with the slots for the spanner wrench forward.
 - (2) Screw the valve seat (298737-2) into the end of the throttling rod, fasten with a taper pin (No. 000 x 1").
- b.** Assemble the nut, spring, and check valve.
 - (1) Install the check valve (298732-7), spring (298732-2), and nut (298732-1).
 - (2) Fasten the nut with the taper pin (No. 000 x 1").
- c.** Install the piston rod and the packing rings.
 - (1) Install the piston rod (298734-1) in the cylinder (298730-1).
 - (2) Install the front gland ring (298732-6), the leather packing ring (298735-3), the center gland ring (298735-4), the four chevron packing rings (298735-1), the rear gland ring (298735-2), and the gland bushing (298739-5). Tighten the gland bushing with spanner wrench (298870-1).
- d.** Install the securing pin.
 - (1) Tap in the securing pin (298738-1).
 - (2) Insert the locking screw (298739-1).
- e.** Install the throttling rod assembly.
 - (1) Push in the piston rod (298734-1).
 - (2) Install the leather washer (298739-6) and the throttling rod assembly.

- f. Tighten the throttling bushing, **Figure 52**, and install the locking screw.
- (1) With spanner wrench (298874-1), tighten the throttling bushing (298732-8) and install the locking screw (1/4"—20 x 5/16").




Figure 51
Recoil cylinder disassembled

TIGHTENING THROTTLING BUSHING




Figure 52

- g.** Tighten the throttling rod and install the needle valve.
- (1) Holding the recoil cylinder either in a vise or with spanner wrench (298870-2), tighten the throttling rod (298736-2), using spanner wrench (298870-1).
 - (2) Assemble the packing ring (298732-4) and the steel gland ring (298732-5) on the needle valve (298736-1).
 - (3) Screw in the needle valve and tighten the gland nut (298739-3).
 - (4) Install the locking screw (298739-2).
- h.** Fill the recoil cylinder.
- (1) Unscrew the needle valve two turns.
 - (2) Install the drain plug (298739-7) and washer (298739-4), and with the forward end of the cylinder raised to a 25 degree incline, fill the cylinder to overflowing with liquid. Install the fill plug (298739-7) and tilt the cylinder slowly several times. Again fill the cylinder to overflowing while inclined at 25 degrees.
 - (3) Install the fill plug and washer (298739-4) and wire the plugs together.

- i. Install the locking plate.
 - (1) Turn the needle valve all the way in, and then turn it back 1/3 turn.
 - (2) Install the locking plate (298738-3), the retaining bolt (5/16"—24 x 5/8"), the washer (5/16"), and the lock washer (5/16").

C. LOADER ASSEMBLY

1. Removal of the Loader Assembly

- a. Open the rear door.
 - (1) Remove the through bolt and lower the rear door, **Figure 53**.
- b. Remove the tray bolt.
 - (1) Insert the key (298871) in the lock in the side door, pressing in firmly to release the bolt spring, and turn the key to open the door.
 - (2) Insert wrench (298869-6) in the slot in the head of the rammer tray bolt. Push the bolt in against spring tension and rotate it 1/4 turn in either direction to remove, **Figure 54**.



Figure 53

Rear door—open.




Figure 54

Removing the tray bolt.

- c. Remove the loader assembly.

For this operation, front lifter (346451) and rear lifter (346452) are required.

 - (1) Slide the assembly part way back, and with two men applying the rear lifter and one the front lifter, raise the assembly as it leaves the supporting guides in the slide, **Figure 55**.

To prevent damage do not allow the assembly to rest or drop on the rear door.

USING LOADER LIFTERS





Figure 55

The top view shows one man with lifter tool (346451) and two others with lifter tool (346452). In the bottom picture, the lifters are in place and the loader ready to be removed.

2. Installation of the Loader Assembly

- a. Install the loader assembly.
For this operation front lifter (346451) and rear lifter (346452) are required.
 - (1) Install the lifters and raise the assembly carefully, starting it into the supporting guides in the slide.
 - (2) Remove the lifters and slide the assembly in as far as it will go.
- b. Insert the rammer tray bolt.
 - (1) Insert the wrench (298869-6) in the slot in the head of the bolt (298676-2). Push the bolt in against spring tension and rotate 1/4 turn, matching the two arrows to lock.
 - (2) Close and lock the side door, using the key (298871).
- c. Close the rear door.
 - (1) Swing the rear door (298721-1) up to the closed position.
 - (2) Insert the through bolt (298704-5) and turn it up tightly.

3. Removal of the Rammer Tray

- a. Remove the tray assembly.
The loader assembly must be removed from the slide in order to remove the tray assembly.
 - (1) Pull the tray forward out of the loader assembly, **Figure 56**.
 - (2) Remove the loose rollers from the lower ends of the feed rods.




Figure 56
Removing the rammer tray.




Figure 57
Tray pawls.

4. Installation of the Rammer Tray

- a. Install the tray assembly.
- (1) Install the rollers (298776-6) on the lower ends of the feed rods.
 - (2) Install the tray assembly, sliding it in from the front end of the loader; be careful not to push the tray in far enough that the rammer shoe passes over the catch levers.

5. Disassembly of the Rammer Tray

- a. Remove the tray pawls shown in **Figure 57**.
- (1) Tap out the taper pin and the bearing pins.
 - (2) Remove the pawls, their plungers, and springs.
- b. Remove the rammer shoe nut and the lever bearing screws, **Figure 58**.
- (1) Remove the cotter pin and the nut.
 - (2) Remove the cotter pins and the bearing screws.
- c. Remove the levers, plungers, springs, and the rammer shoe.
- (1) Slide the shoe back to the large slots, press in and down to remove the levers.
 - (2) Remove the plungers, the spring, and the shoe, **Figure 59**.
- d. Remove the spring seat locking screw, and the rammer.
- (1) Remove the locking screw and loosen the spring seat with spanner wrench (298874-2).
 - (2) Remove the rammer assembly.




Figure 58

Removing bearing screw and rammer shoe nut.




Figure 59

Disassembly of the rammer shoe.

- e. Disassemble the rammer.
 - (1) Tap out the taper pin, compress the spring, and unscrew the rammer head from the rod.
 - (2) Remove the spring and the seat.
- Handle the spring carefully to avoid personal injury.**
- f. Remove the rammer buffer.
 - (1) Remove the cotter pin and the castellated nut.
 - (2) Using a rod (3/8" diameter x 15" long), tap out the buffer.

6. Assembly of the Stripped Rammer Tray

- a. Install the rammer buffer.
 - (1) Insert the rammer buffer (298792), stud first, into the rammer chamber.
 - (2) Install and tighten the castellated nut (3/8"—24), and install the cotter pin (3/32" x 1").
- b. Assemble the rammer.
 - (1) Place the rammer spring (298793-1) and spring seat (298793-5) on the rammer rod (298793-3).
 - (2) Compress the spring, and screw the rammer head (298793-2) on the rod.
- c. Install the rammer and the locking screw.
 - (1) Install the rammer assembly in the tray.
 - (2) Screw the spring seat (298793-5) into the rammer chamber with spanner wrench (298874-2) and install the locking screw (298793-4).
- d. Install the rammer shoe, plungers, plunger spring, and rammer levers.
 - (1) Install the rammer shoe (298794-1), the plunger spring (298791-5) and the plungers (298791-6).
 - (2) Slide the rammer shoe (298794-1) back to the large slot, press in and up to install the levers (right, 298795-1; left, 298795-2).
- e. Install the lever bearing screws and the rammer shoe nut.
 - (1) Install the bearing screws (298791-9) and their cotter pins (1/8" x 1-1/4").
 - (2) Install the 1-1/16" rammer shoe nut (298791-7) and the cotter pin (1/8" x 1-1/2").
- f. Install the tray pawls, **Figure 57**.
 - (1) Install the springs (298791-2), the plungers (298791-3), and the pawls (right, 298791-4; left, 298791-1).
 - (2) Insert the bearing pins (298791-8) and drive in the taper pins (No. 00 x 1-1/8").

7. Disassembly of the Loader Assembly

α. Remove the guides and the feed control mechanism.

- (1) Remove the front guide.
 - (a) Remove the two top retaining screws and then the two clamp screws.
- (2) Remove the left rail of the rear guide.
 - (a) Remove the two retaining screws, the lower front screws, the long through screws and the upper front screw.
 - (b) Remove the rails.
- (3) Remove the right rail of the rear guide.
 - (a) Remove the two rear retaining screws and the long through screw.
 - (b) Remove the rail.
- (4) Remove the feed control mechanism, **Figure 60**, and the rear guide.
 - (a) Remove the cotter pin and the clevis pin from the outer arm of the intermediate control spindle, and unscrew the feed control rod from the rod end.
 - (b) Remove the lever and arm retaining screws and tap out the spindle.
 - (c) Remove the spindle arm and rod end, and the feed control lever.




Figure 60

Feed control mechanism removed from the rear guide.

- (d) Disassemble the arm and rod end by removing the cotter pin and the clevis pin.
- (e) Remove the two upper screws, the lower screws and lift off the rear guide.
- (5) Remove the ammunition clip guide.
 - (a) Remove the retaining screws.
 - (b) Lift off the clip guide.

The rear guide must be removed before the clip guide can be taken off.




Figure 61

Removing a star wheel plunger.

b. Remove the frames.

To remove the frame assemblies, the guides must be removed.

- (1) Remove the cross piece cover, the plunger, the spring, and the seat, **Figure 61**.
 - (a) Remove the retaining screw and the cover.
 - (b) Compress the springs in order to remove the seats, the springs, and the plungers.
- (2) Remove the cross piece.
 - (a) Remove the two upper screws, the two lower screws and the cross piece.
- (3) Remove the frame assemblies.
 - (a) Tap out the two taper pins.
 - (b) Remove the six retaining screws from each frame.

c. Remove the star wheels.

The frame assemblies must be removed in order to remove the star wheels.

- (1) Tap out the taper pins.
- (2) Remove the star wheel shaft retaining screws, the shafts, and the star wheels, **Figure 62**.




Figure 62

Removing a star wheel after the retaining screw has been removed. The star wheel shaft and extension piece are being withdrawn from the star wheel.

d. Remove and disassemble the feed rods.

The tray assembly must be removed in order to remove the feed rod assemblies. Instructions for removal are given on page 94. It is not necessary, however, to remove the frame assemblies in order to service the feed rod assemblies. The following instructions apply to either of the feed rods.

- (1) Remove the feed rod assembly.
 - (a) Use an offset screw driver to remove the retaining screw.
 - (b) Rotate the star wheel and raise the assembly out of the frame.

- (2) Remove the feed pawl holder.
For this operation the clamp (298875) is required.
 - (a) Install the clamp and tighten until the spring is completely compressed.
 - (b) Slide the holder and lift it out, **Figure 63**.
 - (c) Loosen the clamp.
 - (d) Remove the plunger and spring.
- (3) Remove the pawls.
 - (a) Push out the bearing pins.
 - (b) Remove the bushings, springs, and pawls.




Figure 63
Removing the feed pawl holder.

- e. Remove and disassemble stop pawls.
The loader assembly need not be removed in order to remove the stop pawl assembly.
 - (1) Remove the stop pawl assembly.
 - (a) Tap out the dowel pin.
 - (b) Remove the screws and washers and lift out the assembly.
 - (2) Remove the pawls.
 - (a) Push out the bearing pins.
 - (b) Remove the bushings, springs, and pawls.
- f. Remove and disassemble the star wheel catch mechanisms.
It is not necessary to remove this assembly when the frame assemblies are to be removed.

- (1) Remove the catch head bracket.
 - (a) Remove the cotter pins and the castellated nuts.
 - (b) Tap out the retaining screws and remove the bracket.
- (2) Remove the catch head.
 - (a) File off the riveted ends of the taper pin.
 - (b) Rotate the catch arm and insert a block between it and the casting to place the catch head taper pin in position to be driven out. Drive out the taper pin, **Figure 64**.
 - (c) Remove the catch head.




Figure 64
Removing the catch head.




Figure 65
Catch head.

- (3) Remove the catch arm, spring and spindle.
 - (a) Tap the taper pin out of the catch arm.
 - (b) Raise the spindles and remove the catch arm and the spring.
 - (c) Remove the spindle through the bottom.
- (4) Disassemble the catch head, **Figure 65**.
 - (a) Remove the retaining screw and the bearing pin.
 - (b) Push out the pawl, the plunger and the spring.

- g. Remove and disassemble the star wheel catch release and the rammer cocking levers.
- (1) Remove the catch release spindle retaining pins.
 - (a) Tap out the three taper pins.
 - (2) Remove the catch release spindle and the catch release levers.
 - (a) Tap out the spindle and pull out the catch release levers.
 - (3) Remove the catch release pistons.
 - (a) Rotate the catch heads and extract the pistons.




Figure 66

Removing the outboard rammer cocking lever.

- (4) Remove the catch release link and the rammer cocking lever shaft arm.
 - (a) Remove the lock screw and the shaft arm.
 - (b) Remove the pin from the shaft arm.
 - (c) Take out the cotter pin and remove the clevis pin from the link.
- (5) Remove the outboard rammer cocking lever, **Figure 66**.
 - (a) Tap out the taper pin.
- (6) Remove the inboard rammer cocking lever and shaft.
 - (a) Tap out the taper pin.
 - (b) Remove the shaft and lever.

- h.** Remove and disassemble the catch lever mechanisms.
- (1) Remove the rammer control spindle.
 - (a) Tap out the taper pin from the fixed tappet.
 - (b) Remove the spindle.
 - (c) Remove the fixed tappet, the free tappet, the spring, and the collar.
 - (d) Tap out the taper pin to remove the arm from the spindle.
 - (2) Remove the catch levers and their plungers.
 - (a) Depress the plungers and install cotter pins or wire in the holes in the lower ends to hold them down.




Figure 67

Removing the catch levers and the bearing pin.

- (b) Tap out the taper pin from the bearing pin.
 - (c) Tap out the bearing pin and remove the loader catch lever (inboard), tray catch lever (center), and the trigger catch lever (outboard), **Figure 67**.
 - (d) Depress the plungers and remove the holding pins or wire.
 - (e) Remove the plungers and the springs.
- (3) Remove the intermediate control spindle and arms.
 - (a) Tap out the taper pin from the outer arm, and remove the inner arm and spindle.
 - (b) Tap out the taper pin to remove the inner arm.
 - (4) Remove the rocker arm.
 - (a) Tap out the taper pin from the bottom of the base.
 - (b) Tap out the bearing pin and remove the lever.

8. Assembly of the Stripped Loader Assembly

α. Assemble and install the catch lever mechanisms.

- (1) Install the rocker arm.
 - (a) Insert the rocker arm (298746-1) and the bearing pin (298748-7).
 - (b) Tap in the taper pin (No. 000 x 1") from the top of the base.
- (2) Install the intermediate control spindle and arms.
 - (a) Install the inner arm (298750-4) on the spindle (298750-3) and fasten with a taper pin (No. 000 x 3/4").
 - (b) Insert the spindle into the base from the inside and attach the outer arm (298752-4) with a taper pin (No. 000 x 7/8").
- (3) Install the catch levers and their plungers.
 - (a) Insert the two end plungers (298748-4), the center plunger (298748-2), and the springs (298748-5) in the holes in the bottom of the base.
 - (b) Depress the plungers and insert wires or cotter pins in the holes in the lower ends to hold them down.
 - (c) Start the bearing pin (298748-1) into the base and thread it through the holes in the following levers: The trigger catch lever (298747-4) (outboard), the tray catch lever (298747-1) (center), and the loader catch lever (298749-4) (inboard). Push the bearing pin the rest of the way into the base.
 - (d) Install the taper pin (No. 1 x 1-1/4").
 - (e) Depress the plungers and remove the holding pins or wire.
- (4) Install the rammer control spindle.
 - (a) Install the arm (298750-2) on the spindle (298750-1) and fasten with a taper pin (No. 000 x 7/8").
 - (b) Start the spindle (298750-1) into the base and thread it through the following: the fixed tappet (298749-2), the free tappet (298749-3), the spring (298749-1), and the collar (298748-8). Push the spindle the rest of the way into the base.
- (5) Adjust the tray catch lever.
 - (a) Turn the adjusting screw (298748-6) in the bottom of the base to bring the tray catch lever level with the two side

levers. After the loader is assembled in the slide, cock the gun and check the clearance between the rammer shoe and the tray catch lever using a $^{\circ}020$ – $^{\circ}050$ thickness gauge and a 3" straight edge. It should be between $^{\circ}020$ – $^{\circ}050$. If it is found that the clearance exceeds $^{\circ}050$, remove the rocker arm and grind off the top surface of the front end. Grind as much material off the rocker arm as is required to bring the clearance to $^{\circ}050$.

If the clearance is found to be less than $^{\circ}020$, replace the lever.

- b. Assemble and install the star wheel catch release and the rammer cocking levers.
 - (1) Install the inboard cocking lever and shaft.
 - (a) Install the shaft (298751-1) and the lever (298751-3) in the base.
 - (b) Install the taper pin (1 x 1-1/4").
 - (2) Install the outboard rammer cocking lever.
 - (a) Install the lever (298769-4) and fasten with a taper pin (No. 1 x 1-1/4").
 - (3) Install the catch release link, the spindle arm, and the rammer cocking lever shaft arm.
 - (a) Assemble the link (298746-3) and the spindle arm (298752-3) with the clevis pin (298746-5) and the cotter pin (1/16" x 1/2").
 - (b) Install the pin (298748-9) through the link and shaft arm (298751-2).
 - (c) Install the shaft arm on the rammer cocking lever shaft, and insert the lock screw (No. 8—32 x 3/8", dog point headless).
 - (4) Install the catch release pistons.
 - (a) Rotate the catch heads and install the pistons (298752-1).
 - (5) Install the catch release levers.
 - (a) Locate the catch release levers (298752-2) in the base and insert the spindle (298746-4). Install the spindle arm on the end of the spindle.
 - (6) Install the catch release spindle retaining pins.
 - (a) Install the three taper pins (No. 1 x 7/8").

- c. Assemble and install the star wheel catch mechanism.
- (1) Assemble the catch head, **Figure 65**, page 101.
 - (a) Install the spring (298785-2), the plunger (298785-5), and the pawl (298785-1) in the catch head.
 - (b) Install the bearing pin (298785-3) and the retaining screw (No. 5—40 x 1/2").




Figure 68

Stop pawls.

- (2) Install the catch arm, spring, and spindle.
 - (a) Insert the spindle (298753-2) through the bottom of the base.
 - (b) Raise the spindle and install the arm (right, 298747-2; left, 298747-3) and the spring (right, 298753-1; left, 298746-2).
 - (c) Tap the taper pin (No. 0 x 3/4") into the arm.
- (3) Install the catch head.
 - (a) Install the catch head (right, 298786-1; left, 298787-1).
 - (b) Tap the taper pin (No. 0 x 1") into the catch head.
 - (c) Rivet the end of the taper pin.

- (4) Install the catch head bracket.
 - (a) Install the bracket (298785-4) and insert the retaining screws (298785-6).
 - (b) Install the castellated nuts (5/16"—24) and insert the cotter pins (1/16" x 5/8").
- d. Assemble and install the stop pawls.
 - (1) Install the pawls in the holder, **Figure 68**.
 - (a) Install the springs (298754-2) and bushings (298754-3) in the pawls (298754-5).
 - (b) Place the pawls in the holder (left, 298756-1; right, 298754-1) and insert the bearing pins (298754-4).




Figure 69

Feed pawls.

- (2) Install the stop pawl assembly.
 - (a) Insert the assembly in the frame.
 - (b) Insert the screws (5/16"—24 x 1-1/8") and washers (5/16").
 - (c) Tap in the dowel pin (5/16" x 1-3/8").
- e. Assemble and install the feed rods.
 - (1) Install the pawls in the holder, **Figure 69**.
 - (a) Assemble the springs (298754-2), bushings (298754-3) and pawls (right, 298758-1; left, 298762-1).
 - (b) Insert the pawls in the holders (left, 298757-2; right, 298761-1) and push in the bearing pins (298754-4).

- (2) Install the feed pawl holder in the feed rod.
For this operation, clamp (298875) is required.
 - (a) Install the plunger spring (298759-1) and the plunger (298759-3) in the feed rod.
 - (b) Install the clamp and tighten until the spring is completely compressed.
 - (c) Insert the holder in the feed rod and slide it down.
 - (d) Loosen the clamp.
- (3) Install the feed rod assembly in the frame.
 - (a) Insert the feed rod assembly in the slot in the frame, rotating the star wheel as the feed rod is pushed down to the bottom of the groove.
 - (b) Using an offset screwdriver, install the retaining screw (298759-2).
- f.** Install the star wheels.
 - (1) Assemble the star wheel on the shaft (left, 298774-1; right, 298771-1) and install it in the loader with the retaining screw (298776-1).
 - (2) Tap in the taper pin (No. 000 x 7/8").
- g.** Install the frames.
 - (1) Install the frame (right, 298764-1; left, 298763-1) and insert the six retaining screws (3/8"—24 x 5/8").
 - (2) Tap in the two taper pins (No. 7 x 2").
- h.** Install the star wheel plungers.
 - (1) Install the cross piece.
 - (a) Install the cross piece (298769-1), the two lower screws (3/8"—24 x 7/8").
 - (2) Install the star wheel plungers, springs, and seats, and the cross piece cover.
 - (a) Install the plungers (298777-1), the springs (298777-2), and the seats (298777-3).
 - (b) Install the cross piece cover (298769-3) and the retaining screw (1/4"—28 x 1/2").
- i.** Install the guides and the feed control mechanism.
 - (1) Install the ammunition clip guide.

- (a) Install the guide (298769-2) and the retaining screws (5/16"—24 x 1/2").
- (2) Install the rear guide and feed control mechanism.
 - (a) Install the rear guide (298767-1), and insert the four retaining screws (3/8"—24 x 7/8").
 - (b) Assemble the rod end (298777-4) and the spindle arm (298753-3) with the clevis pin (298748-3).
 - (c) Install the cotter pin (1/16" x 5/8").
 - (d) Insert the spindle (298784-3), and install the lever and arm retaining screws (298776-9).
 - (e) Screw the rod (298776-8) into the rod end (298777-4).
- (3) Install the right rail.
 - (a) Install the rail (298778-1) and insert the long through screw (298776-2) and the two rear retaining screws (5/16"—24 x 3/4").
- (4) Install the left rail.
 - (a) Install the two rails (298782-1 and 298780-1).
 - (b) Install the upper front screw (5/16"—24 x 1"), the long through screw (298776-2), the lower front screws (5/16"—24 x 1/2"), and the two rear retaining screws (5/16"—24 x 3/4").
- (5) Install the front guide.
 - (a) Install the front guide (298766-1).
 - (b) Install the two clamp screws (298776-3) and the two top retaining screws (3/8"—24 x 5/8").
- (6) Adjust the feed control mechanism.
 - (a) Install a ".25 gauge block or thickness gauge under the front end of the loader catch lever (inboard).
 - (b) Insert two dummy rounds in the loader to position the feed control lever in the rear guide. Hold up in position the outer arm on the intermediate control spindle, and adjust the length of the feed control rod until all the up and down motion is eliminated. When the clevis pin (298748-3) is inserted, install the cotter pin (1/16" x 5/8").

D. HOUSING ASSEMBLY

The barrel, recoil cylinder and loader assemblies must be removed before the housing can be removed or installed, and the slide should be in a horizontal position.

1. Removal and Disassembly of the Housing Assembly

It is unnecessary to remove the housing assembly for removal or installation of the extractors, the breech block assembly, the closing spring assembly, the outer crank assembly, and the inner cranks.

a. Remove the barrel assembly.

Instructions for removing the barrel assembly are given on page 80.




Figure 70

Removing the extractors.

b. Remove the loader.

Instructions for removing the loader assembly are given on page 92.

c. Remove the recoil cylinder.

Instructions for removing the recoil cylinder assembly are given on page 87.

- d. Remove the bottom cover.
 - (1) Pull down on the knurled head and swing the lever to one side to release the arm.
 - (2) Allow the cover to drop out of place.
- e. Remove the breech block.

Instructions for removing the breech block assembly are given on page 115.
- f. Remove the housing.
 - (1) Close the top door and pull the housing out of the back end of the slide.
- g. Remove the extractors.

For this operation the extractor spindle tool (299204-1) is required.

 - (1) Screw the tool into the threaded end of the extractor spindle, swing both extractors to the extreme rear position, and then swing the extractor spindle arm to the extreme forward position.
 - (2) Pull out the spindle and dismount the extractors through the bottom of the housing, **Figure 70**.
 - (3) Swing the extractor spindle arm to the extreme rear position and remove it from the breech housing.
- h. Remove the barrel lock.
 - (1) Swing the barrel lock up, pull the safety catch arm out of the housing, and remove the barrel lock.
- i. Remove the safety plunger.
 - (1) Use wrench (298869-5) to unscrew the spring seat.
 - (2) Remove the spring and the safety plunger.
- j. Remove the crankshaft bushing.
 - (1) Remove the locking screw.
 - (2) Slide the crankshaft bushing out of the housing.
- k. Remove the tray bolt spring seat.
 - (1) Remove the locking screw and unscrew the spring seat, using wrench (298869-6), **Figure 71**.
 - (2) Remove the spring and the sleeve.
- l. Remove the barrel stop.
 - (1) Remove the barrel stop retaining screw and pull the barrel stop out of the housing, **Figure 72**.

- m.** Remove the outer crank from the crankshaft.
- (1) Remove the elastic stop nut, tap out the lock pin and remove the crank from the shaft.
 - (2) Remove the screw, washer, and the roller.
- n.** Remove the breech block closing spring.
- (1) Mount the closing spring assembly on the bracket at the rear of the carriage platform and use wrench (298868-1) to remove the cover, **Figure 73**. To do this, push the cover in against spring tension and turn it to the left to release.
 - (2) Remove the spring.
 - (3) Remove the spring case from the bracket.




Figure 71

Removing the tray bolt spring seat.




Figure 72

Removing the barrel stop.

DISASSEMBLY OF THE CLOSING SPRING




Figure 73

When being assembled or disassembled the closing spring assembly is mounted in a bracket on the rear of the carriage platform.

2. Assembly and Installation of the Housing Assembly

a. Assemble the crankshaft.

- (1) Install the roller (298672-3), washer (298672-4), and screw (298672-7) on the crank.
- (2) Mount the crank (298687-1) on the shaft (298687-2) and install the lock pin (298681-3) and the elastic stop nut (299210-1).

b. Assemble the breech block closing spring.

- (1) Install the spring case (298685-4) in the bracket on the rear of the carriage platform and install the spring (298685-1), convex side out, in the case.
- (2) To install the cover (298685-3) it is necessary to press the cover in against spring tension as it is being turned to the right by the wrench (298868-1) to lock it to the case.

c. Install the barrel stop.

- (1) Insert the barrel stop (298673-2) in the housing and install the retaining screw (298672-7). Tighten the screw firmly.

d. Install the tray bolt seat and spring.

- (1) Insert the sleeve (298676-4), the spring (298676-6), and the seat (298676-7) in the inboard lug on the housing and screw the seat in tightly, using wrench (298869-6).
- (2) Install the locking screw (1/4"—20 x 1/4").

- e. Install the crankshaft bushing.
 - (1) Slide the bushing (298672-8) into position in the housing and insert the locking screw (298672-2).
- f. Install the safety plunger.
 - (1) Install the safety plunger spring (298676-3) and the safety plunger (298676-5) in the housing.
 - (2) Insert the spring seat (298676-1) and screw it in tightly, using wrench (298869-5).
- g. Install the barrel lock.
 - (1) Place the barrel lock (298673-1) in an upright position in the housing and install the safety catch arm (298671-2).
- h. Install the extractors.

For this operation, extractor spindle tool (299204-1) is required.

 - (1) Assemble the extractors (298674-1 and 298674-2) together and place them in position in the housing with the hooked sides down.
 - (2) Install the extractor spindle arm (298675-1) by swinging it rearward and pushing it all the way into position.
 - (3) With the extractor assembly in the rear position and the extractor spindle arm swung forward, install the spindle (298674-3).
- i. Install the housing.
 - (1) Install the housing in the rear end of the slide, and push the housing all of the way forward. Open the top door to retain the housing in position.
- j. Install the breech block.

Instructions for installing the breech block are given on page 118.
- k. Install the bottom cover.
 - (1) Install the cover (298705-1) in position, and lock it by lifting the knurled head (298701-3) and swinging the lever (298713-4) to one side until it latches in the rear notch in the cover.
- l. Install the recoil cylinder.

Instructions for installing the recoil cylinder are given on page 87.
- m. Install the loader.

Instructions for installing the loader are given on page 94.
- n. Install the barrel assembly.

Instructions for installing this assembly are given on page 81.

E. BREECH BLOCK ASSEMBLY

1. Removal and Disassembly of the Breech Block Assembly

The breech block assembly may be removed and installed with the barrel removed or in position in the housing and slide.

The breech block may also be removed and installed with the gun mechanism in a horizontal or depressed position.

If the gun mechanism is mounted on the carriage, it is preferable to depress the gun to a convenient working angle.

To remove the breech block assembly the gun must be unloaded and the breech block uncocked.




Figure 74

Opening the side door.

- a. Open the top door.
 - (1) To open the top door, lift the knurled head to release the lever and swing it to one side to unlatch the door.
 - (2) Swing the top door fully open to engage its locking catch.
- b. Open the side door.
 - (1) Insert the key (298871) and turn it to release the catch.
 - (2) Swing the door open, **Figure 74.**

USING THE HAND EXTRACTOR TOOL




Figure 75

- c. Remove the bottom cover.
 - (1) Pull down on the knurled head and swing the lever to one side to release the arm and the cover.
- d. Remove the breech block closing spring assembly.
 - (1) Pull the crankshaft out about 2" and remove the closing spring assembly.

If the crankshaft is stuck and cannot be easily pulled out, pry it out with the hand extractor (298871-1), **Figure 75**.

- e. Remove the inner cranks.
 - (1) Support the breech block assembly and withdraw the crankshaft.
 - (2) Lower the breech block until it engages the safety plunger, and remove the inner cranks.

REMOVING THE BREECH BLOCK




Figure 76

While one man withdraws the crankshaft, another is shown removing the inner cranks and the breech block.

If the barrel is in position, the safety plunger will not function and the breech block assembly will come out with the inner cranks, Figure 76.

- f. Remove the breech block.
 - (1) Insert the safety plunger key (299206) in the hole in the top of the housing and turn it to release the breech block assembly.
 - (2) While turning the key, catch the breech block as it slides out of the bottom of the housing.

- g. Remove the firing pin.
- (1) Insert the wrench (298869-6) in the slot in the firing spring cover, **Figure 77**, push the cover in against spring tension, and give it a quarter turn in either direction to remove.
 - (2) Remove the firing spring and the firing pin.
- h. Remove the firing hole bushing.
- (1) Tap against the smooth end, but do not try to force the pin all the way out of the breech block.
 - (2) Insert the wrench (298869-6) from the rear of the breech block and unscrew (clockwise) the firing hole bushing. Remove the locking pin.




Figure 77

Removing the firing spring cover.




Figure 78

Removing the outer cocking lever.

- i. Remove the cocking levers and the sear.
- (1) Push the sear in against spring tension, and remove the outer cocking lever, **Figure 78**.
 - (2) Remove the inner cocking lever, the sear, and the sear spring.

2. Assembly and Installation of the Breech Block Assembly

- α. Install the sear and cocking levers.
- (1) Install the sear spring (298681-2), the sear (298680-1) and the inner cocking lever (298682-4).

- (2) Push the sear in against spring tension and insert the outer cocking lever (298680-2).
- b.** Install the firing hole bushing.
- (1) Insert the locking pin (298681-4) with the curved slot to conform with the shape of the hole for the bushing.
 - (2) Screw in the bushing (298682-2), tighten it with the wrench (298869-6) and use a 1/8" drift in driving the locking pin tight, driving against the slotted end.
- c.** Install the firing pin.
- (1) Insert the firing pin (298682-3) and the firing spring (298681-1).
 - (2) Insert the wrench (298869-6) in the slot in the firing spring cover, push the cover (298682-1) in against spring tension, and give it a quarter turn to match the arrows.
- d.** Install the breech block.
- (1) Insert the safety plunger key (299206) in the hole in the top of the housing and turn it to retract the safety plunger.
 - (2) Slide the breech block up from the bottom. Turn the key to release the safety plunger, and allow the breech block to slide down until it is locked by the safety plunger.

If the barrel is in position, the safety plunger is not operative and the block, the inner cranks, and the crankshaft must be installed at the same time.

- e.** Install the inner cranks.
- (1) Insert the inner cranks (left, 298683-1; right, 298683-2), and after retracting the safety plunger with the key, slide the breech block and cranks up in the housing as far as they will go, tripping the extractor release lever so that the block will clear the extractor.
 - (2) Insert the crankshaft (298686), with the flat surface on the lower arm of the outer crank parallel with the bottom of the side door, pushing it in far enough to support the breech block and inner cranks but not far enough to prevent the assembly of the closing spring.
- f.** Install the closing spring assembly.
- (1) Slide the closing spring assembly up in the T slot in the side of the housing and push the crankshaft all the way in.
- g.** Install the bottom cover, close and lock the side door and top doors.

F. SLIDE ASSEMBLY

1. Removal and Disassembly of the Top Door

The top door assembly may be removed at any time without disturbing any of the other units. The door catch and locking catch assemblies may be removed without dismounting the door.

Make sure the gun is unloaded and uncocked before removing the top door. If the barrel is dismounted, install the breech block locking bolt (298716-1).

a. Remove the top door.

- (1) Open the top door by lifting the knurled head and swinging the lever to one side.
- (2) Remove the two retaining screws and tap the door assembly gently to dislodge the dowel pin.
- (3) Carry the door forward to disengage it from the barrel lock.




Figure 79

Top door assembly.

b. Remove the locking catch assembly.

- (1) Remove the four retaining screws and dismount the catch assembly.
- (2) To disassemble the locking catch assembly, remove the retaining pin, the pivot pin, the locking catch, and the spring from the bracket.

- c. Remove the door catch.
 - (1) Remove the taper pin, the arm, and the lever.
 - (2) The knurled head, the plunger, and spring, may be removed by grinding off the riveted end of the plunger.
- d. Remove the door hinge.
 - (1) Remove the retaining pin, the hinge pin and the hinge from the top door.

2. Assembly and Installation of the Top Door, Figure 79

The door catch and the locking catch assemblies may be installed before or after the door is installed on the slide.




Figure 80
Installing the top door.

- a. Install the hinge on the door.
 - (1) Install the hinge (298699-1), the hinge pin (298699-4), and the taper pin (No. 000 x 5/8").
- b. Install the door catch assembly.
 - (1) Install the lever (298713-4), the arm (298701-1), and the taper pin (No. 0 x 1").
- c. Install the locking catch assembly.
 - (1) To install the locking catch assembly, install the spring (298699-3), the catch (298699-2), the pivot pin (298703-4), and the taper pin (No. 000 x 5/8").

- (2) Mount the catch assembly in position on the door and install the four retaining screws (10—32 x 1/2").
- d. Install the top door.
 - (1) Insert the barrel lock in the top door guide, **Figure 80**, and then slide the door rearward into position.
 - (2) Install the hinge retaining screws (5/16"—24 x 1/2") and the dowel pin (No. 2 x 3/4").
 - (3) After the door is closed, lift the knurled head (298701-3) and swing the lever (298713-4) forward to engage the arm (298701-1).

3. Removal and Disassembly of the Side Door

The side door assembly may be removed at any time without disturbing any of the other units. The catch may be removed without dismounting the side door.

Make sure the gun is unloaded and uncocked.

- a. Remove the side door.
 - (1) Open the side door with the key.
 - (2) Remove the door hinge bolt and take off the door assembly.
- b. Remove the catch, **Figure 81**.
 - (1) Remove the spring retaining screw and slide the spring out toward the door hinge.




Figure 81
Removing the side door catch.

- (2) Remove the indicating screw and slide the catch out of position.

4. Assembly and Installation of the Side Door

a. Install the catch.

- (1) Slide the catch bolt (298701-6) into position and install the indicating screw (298831-4).
- (2) Slide the spring (298701-5) into position and install the spring retaining screw (1/4"—28 x 5/8").

b. Hang the side door.

- (1) Install the door hinge bolt (298703-1) after the door (298702) has been placed in position.
- (2) Close and lock the side door with the key (298871).

5. Removal and Disassembly of the Bottom Cover

The bottom cover assembly may be removed at any time without disturbing any of the other units.

a. Remove the bottom cover.

- (1) Pull down the knurled head and swing the lever to one side to release the cover assembly.

b. Remove the cover catch.

- (1) Remove the taper pin, the arm and the lever.
- (2) The knurled head, the plunger, and the spring may be removed by grinding off the riveted end of the plunger.




Figure 82
Bottom cover.

6. Assembly and Installation of the Bottom Cover, Figure 82

- a. Install the cover catch.
 - (1) Assemble the spring (298701-4), the plunger (298701-2), and the knurled head (298701-3).
 - (2) Insert the lever (298713-4) in the cover (298705-1) and attach the arm (298701-1) with a taper pin (No. 0 x 1").
- b. Install the cover.
 - (1) Insert the flanged edge of the cover into the rear part of the cover opening, and swing the cover up into place.
 - (2) Swing the cover catch to lock the cover in place.

7. Removal and Disassembly of the Rear Door

The rear door assembly may be removed at any time without disturbing any of the other units. The case deflector, the deflector brackets and the recoil indicator assembly may be removed without dismounting the rear door.

Make sure the gun is unloaded before removing the rear door.

- a. Remove the rear door.
 - (1) Remove the through bolt.
 - (2) Remove the taper pin, hinge pin, and the door assembly.The door must be partly closed in order to remove the taper pin.
- b. Remove the recoil indicator, **Figure 83**.
 - (1) Remove the taper pin, nut, spring, washer and the indicating arm.
 - (2) Remove the retaining screws, the washer and the indicating plate, and the stud.
- c. Remove the case deflector and brackets, **Figure 84**.
 - (1) Remove the cotter pin, castellated nut, hinge bolt, securing pin and the deflector.
 - (2) Remove the bracket retaining screws and the brackets.

8. Assembly and Installation of the Rear Door

- a. Install the case deflector brackets.
 - (1) Install the brackets (298722-1 and 298722-2) and insert the retaining screws (3/8"—24 x 7/8").
 - (2) Install the deflector (298723-1) and insert the hinge bolt (298724-2), the castellated nut (3/8"—24) and the retaining cotter pin (3/32" x 1").
 - (3) Install the securing pin (298724-1).

b. Install the recoil indicator.

- (1) Install the stud (298726-1), the indicating plate (298725-2), the retaining screws (5/16"—24 x 3/8"), and the washers (5/16").
- (2) Install the indicating arm (298809-2), the washer (298726-3), the spring (298726-2), the retaining nut (298725-3), and the taper pin (No. 00 x 1").




Figure 83

Removing recoil indicator.




Figure 84

Removing case deflector brackets.

- (3) Position the indicating plate so that the indicating arm will give a true indication of the amount of recoil. To do this, set the arm so that the front surface of the stud at its lower end is at a given distance back of the rear end of the tray. Seven or eight inches or any dimension that is engraved on the plate can be used. With the indicating arm definitely located, loosen the screws holding the indicating plate, and adjust the plate so that the upper end of the indicating arm indicates the same dimension as was used for locating the indicating arm in relation to the tray.

If, for example, the lower end of the indicating arm is positioned 7."5 back of the tray, the plate should be set so that the upper end of the arm reads 7."5 on the plate.

9. Removal and Disassembly of the Hand Operating Mechanism, Figure 85

The removal and disassembly of the hand operating mechanism necessitates the removal of the loader and the housing assemblies. The hand operating lever and both catch bracket assemblies may be removed without disturbing any of the other units.

a. Remove the hand operating lever.

- (1) Remove the locking screw and tap out the retaining pin.
- (2) Remove the hand operating lever.




Figure 85

Interior of the slides.

- b. Remove the hand operating rod, crank, and shaft.
 - (1) Remove the elastic stop nuts and the screws from the rear bracket.
 - (2) Remove the cotter pin, retaining nut, and the washer from the front crank.
 - (3) Move the hand operating rod, crank, and shaft inward toward the center of the slide and remove.
- c. Disassemble the hand operating rod, crank, and shaft.
 - (1) Remove the cotter pins and the clevis pins and remove the crank and the rod.
 - (2) Remove the taper pin and pull the arm and bracket off the hand operating lever shaft.
- d. Remove and disassemble the catch brackets.
 - (1) Remove the retaining screws and the catch bracket assemblies.
 - (2) To disassemble the catch brackets remove the seat, spring and the plunger from the bracket.

10. Assembly and Installation of the Hand Operating Mechanism

- a. Assemble and install the catch brackets.
 - (1) Install the plunger (298724-4) and the spring (298724-5) in the bracket (298708-4), and the screw in the spring seat (298724-3).
 - (2) Install the catch bracket assemblies, and insert the retaining screws (3/8"—24 x 5/8").
- b. Assemble the hand operating rod, crank, and shaft.
 - (1) Assemble the bracket (298713-2) and the arm (298713-1) on the hand operating lever shaft (298711-1) and secure the arm to the shaft with the taper pin (No. 0 x 1").
 - (2) Assemble the hand operating rod (298712-1) on the front crank (298712-2) and the hand operating lever shaft with the clevis pins (298712-4) and the cotter pins (1/8" x 3/4").
- c. Install the hand operating rod, crank, and shaft.
 - (1) Insert the assembly, the slide, and push the hand operating lever shaft through its bushing in the side of the slide.
 - (2) Install the screws (298712-5) in the bracket, and put on the elastic stop nuts (3/8"—24).
 - (3) Install the washer (1/2") and the retaining nut (1/2"—20) on the front crank, and insert the cotter pin (1/8" x 1-1/4").
- d. Install the hand operating lever.
 - (1) Install the hand operating lever (298714-1).
 - (2) Drive in the retaining pin (298712-3), and install the locking screw (1/4"—20 x 3/8").

11. Removal and Disassembly of the Trigger Mechanism

To remove and disassemble the trigger mechanism it is first necessary to remove the loader.

- a.** Loosen the firing lever assembly.
 - (1) Remove the firing lever spring stud.
 - (2) Unhook the trigger spring from the trigger and its stud.
 - (3) Remove the connecting screws and the firing lever spring.
- b.** Remove and disassemble the firing lever.
 - (1) Remove the lock screw, and tap the bearing pin out of the bracket.
 - (2) Remove the lever assembly from the slide.
 - (3) Remove the cotter pin, bearing pin, pawl, plunger, and the spring from the firing lever.
- c.** Remove the firing plunger and crank assembly.
 - (1) Remove the pivot pin, and dismount the crank assembly.
 - (2) Remove the firing plunger from the inside of the slide.
- d.** Disassemble the crank assembly.
 - (1) Remove the cotter pin, the clevis pin and the crank.
 - (2) Loosen both lock nuts, and remove the rod ends and lock nuts from the firing rod.
- e.** Remove the firing selector lever and the trigger.
 - (1) Remove the taper pin, the firing selector lever and the cam.
 - (2) The knurled head, the plunger, and the spring may be removed from the lever by grinding off the riveted end of the plunger.
 - (3) Remove the taper pin, the bearing pin, and the trigger.

12. Assembly and Installation of the Trigger Mechanism

- a.** Install the firing selector lever and the trigger.
 - (1) Assemble the plunger (298701-2), the spring (298701-4), and the knurled head (298701-3) with the lever (298720-9).
 - (2) Install the cam (298708-3) through the side of the slide, and attach the firing selector lever with the taper pin (No. 00 x 1").
 - (3) Install the bearing pin (298699-5), the trigger (298727-2) and drive in the taper pin (No. 000 x 3/4").
- b.** Assemble the crank assembly.
 - (1) Assemble the rod ends (298720-2) on the rod (298720-1), locking them with the lock nuts (1/4"—28).
 - (2) Attach the crank (298710-1) to the firing rod by means of the clevis pin (298720-6), and fasten with the cotter pin (1/16" x 1/2").

- c. Install the crank assembly and firing plunger in the trunnion.
 - (1) Insert the firing plunger (298697-1) from the inside of the slide.
 - (2) Install the crank assembly and the pivot pin (298710-2).
- d. Assemble and install the firing lever.
 - (1) Assemble the spring (298719-2), the plunger (298704-2), the pawl (298717-4), the bearing pin (298719-1), and the cotter pin (1/16" x 1") in the firing lever (298718-1).
 - (2) Place the assembly in the slide, and install the bearing pin (298704-3) in the bracket (298708-2). Install the lock screw (1/4"—20 x 1/2").
- e. Attach the trigger mechanism springs and the firing rod.
 - (1) Install the firing lever spring (298720-5) and attach the firing rod with connecting screws (298693-5).
 - (2) Install the firing lever spring stud (298720-3) and the trigger spring stud (298699-6) and attach the trigger spring (298727-3) and the firing lever spring.




Figure 86

Detail of the interior of the slide.

13. Removal of the Extractor Release Lever

To remove or install the extractor release lever it is necessary to have the housing out of the slide.

α. Remove the extractor release lever, Figure 86.

- (1) Unhook the spring from the lever and from the anchor stud.
- (2) Remove the bracket retaining screws and remove the bracket, lever, and stud from the slide.
- (3) Remove the cotter pin; unscrew the bearing screw, and remove the lever from the bracket.

14. Installation of the Extractor Release Lever**α. Install the extractor release lever.**

- (1) Assemble the lever (298717-1) on the bracket (298717-2) with the bearing screw (298717-3); lock with the cotter pin (1/8" x 1").
- (2) Install the bracket and lever in the slide and insert the retaining screws (5/16"—24 x 3/4").
- (3) Install the anchor stud (298698-9) in the slide, and hook the spring (298703-3) between the stud and the lever.

15. Removal of the Buffer Pad

To remove and install the buffer pad, the housing and recoil cylinder must be removed from the gun.

α. Remove the buffer pad.

- (1) Loosen or remove the six set screws on the outside of the slide.
- (2) Remove the retaining screws and the buffer pad.

16. Installation of the Buffer Pad

- α.** Install the buffer pad (298720-8) and the retaining screws (298720-7).
- b.** Install and tighten the set screws (1/4"—20 x 1/2") on the outside of the slide.

17. Removal of the Breech Block Locking Bolt Bracket and the Housing Stop

The breech block locking bolt bracket or the housing stop may be removed at any time without disturbing any of the other units.

α. Remove the locking bolt bracket.

- (1) Remove the retaining screws, the spring, and the bracket.

b. Remove the housing stop.

- (1) Remove the retaining screws, and pull the stop out of the side of the slide.

18. Installation of the Housing Stop and the Breech Block Locking Bolt Bracket**α. Install the housing stop.**

- (1) Mount the stop (298708-1) in position in the slide and install the retaining screws (3/8"—24 x 5/8").

- b. Install the breech block locking bolt bracket.
 - (1) Locate the bracket (298715-1) on the side of the slide.
 - (2) Install the spring (298712-6) and insert the five retaining screws (No. 10—32 x 1/2").

G. SIGHT ASSEMBLY

The following instructions apply to either the Mark 3 or Mark 4 sight assembly.

1. Removal of the Sight Assembly

- a. Remove the bolts and lockwashers which attach the arm weldment to the slides.
- b. Remove the sight assembly.
- c. Remove the dowel pins.

2. Installation of the Sight Assembly

- a. Place the sight assembly in position and install the bolts (1/2"—20 x 1") and the 1/2" external tooth lockwashers, turning the bolts down lightly.
- b. Install the dowel pins (299277-4).
- c. Tighten the bolts.
- d. Check the alignment of sights as described in Chapter IV.

3. Disassembly of the Sight Assembly

The following instructions apply to either the pointer's or trainer's sight assembly.

- a. Remove the sight guard weldment.
 - (1) Remove the lock nuts and bolts and lift off the sight guard weldment.
- b. Remove and disassemble the pointer's and trainer's sight assemblies.
 - (1) Remove the lock nuts and bolts and remove the cap.
 - (2) Remove the assembly and tap out the key.
 - (3) Remove the front sight.
 - (a) Remove the lock nuts and bolts and remove the front sight bracket.
 - (b) Lift out the front sight.
 - (c) Screw off the adjusting collar.
 - (d) Tap the taper pin out of the ferrule.
 - (e) Remove the ferrule from the bar.

- (4) Remove the rear sight.
 - (a) Tap the taper pin out of the rear sight.
 - (b) Remove the rear sight from the bar.
 - (c) Remove the expansion plug from the bar.

4. Assembly of the Stripped Sight Assembly

- a.** Assemble and install the pointer's and trainer's sight assemblies.
 - (1) Install the rear sight.
 - (a) Insert the expansion plug (345897-259) in the sight bar (299350-1).
 - (b) Install the rear sight (299349-2) on the sight bar.
 - (c) Install the taper pin (No. 4 x 1-1/2").
 - (2) Install the front sight.
 - (a) Install the ferrule (299349-4) on the sight bar.
 - (b) Tap in the taper pin (No. 4 x 1-1/2").
 - (c) Screw the adjusting collar (299346-2) onto the front sight (299342-1).
 - (d) Locate the front sight with adjusting collar in the corresponding channels of the ferrule, with the keyway of the sight bar on the inboard side.
 - (e) Install the front sight bracket (299346-3).
 - (f) Install the bolts (3/8"—24 x 1-1/2"), the 3/8" flat washers, and lock nuts (3/8"—24).
 - (3) Install the sight assemblies (299343-1, trainer's; 299343-2, pointer's) on the arm weldment (299344-1, Mark 3; 299345, Mark 4) with the key (299346-1) in the keyway.
 - (4) Install the cap (299350-2).
 - (5) Install the bolts (3/8"—24 x 1-1/4") and lock nuts (3/8"—24).
- b.** Install the sight guard weldment.
 - (1) Locate the sight guard weldment (345493) and bolt in place with the bolts (3/8"—24 x 2-3/4") and lock nuts (3/8"—24).

Chapter X

PARTS LIST

This Parts List includes the names and Ordnance numbers of all pieces and assemblies included in

40MM Gun Barrel, Mark 1

**40MM Machine Gun Mechanisms, Mark 1 and Mark 2 and Mark 1,
Mod. 1 and Mark 2, Mod. 1**

40MM Sights, Mark 3 and Mark 4.

Column 1 gives the name of the piece or assembly.

Column 2 indicates whether the piece or assembly is part of a Mark 1 or Mark 2 Mechanism or a Mark 3 or Mark 4 Sight.

Column 3 gives the Ordnance number of the Mod. 0 piece or assembly.

Column 4 gives the Ordnance number of the Mod. 1 piece only when it is not interchangeable with the Mod. 0 piece.

Column 5 lists references to illustrations throughout the pamphlet in which the piece or assembly is shown. No reference is given in the case of certain Mark 2 pieces which are similar in appearance to corresponding Mark 1 pieces, or in the case of a few small parts not shown in any illustration.

Order parts from Lists of Drawings only.

Parts List – Barrel Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
40MM Barrel Mark 1		298652	Figure 28 Page 51
Water Jacket	1 & 2	298659-1	Figure 28 Page 51
Attaching Nut	1 & 2	298662-1	Figure 28 Page 51
Set Screw	1 & 2	298662-3	Figure 28 Page 51
Rear Packing Ring	1 & 2	298658-2	Figure 28 Page 51
Gland Nut	1 & 2	298662-2	Figure 28 Page 51
Packing Ring	1 & 2	298658-3	Figure 28 Page 51
Packing Ring	1 & 2	298658-4	Figure 28 Page 51
Packing Ring	1 & 2	298658-5	Figure 28 Page 51
Recoil Spring	1 & 2	298666-1	Figure 28 Page 51
Rear Spring Seat	1 & 2	298666-3	Figure 28 Page 51
Front Spring Seat	1 & 2	298666-2	Figure 28 Page 51
Spring Keeper	1 & 2	298662-4	Figure 28 Page 51
Flash Hider	1 & 2	298663-1	Figure 28 Page 51
Gasket	1 & 2	298658-6	Figure 28 Page 51
Drain Plug	1 & 2	298739-7	Figure 28 Page 51
Washer	1 & 2	298739-4	Figure 28 Page 51

Parts List – Recoil Cylinder Assembly

Name	Mark	Ordinance Number		Reference
		Mod. 0	Mod. 1	
Recoil Cylinder Assembly	1	298729	Figure 21 Page 37
Recoil Cylinder Assembly	2	345989
Cylinder	1	298730-1	323887-1	Figure 51 Page 90
Cylinder	2	298836-1	324103-1
Throttling Rod Assembly	1 & 2	298733
Throttling Rod	1 & 2	298736-2	323890-1	Figure 51 Page 90
Valve Seat	1 & 2	298737-2	323890-2	Figure 21 Page 37
Check Valve	1 & 2	298732-7	Figure 51 Page 90
Valve Spring	1 & 2	298732-2	Figure 21 Page 37
Valve Seat Nut	1 & 2	298732-1	Figure 21 Page 37
Piston Rod Assembly	1 & 2	298733
Piston Rod	1 & 2	298734-1	Figure 51 Page 90
Securing Pin	1 & 2	298738-1	Figure 51 Page 90
Locking Screw	1 & 2	298739-1	Figure 51 Page 90
Throttling Bushing	1 & 2	298732-8	Figure 21 Page 37
Front Gland Ring	1 & 2	298732-6	Figure 51 Page 90
Leather Packing Ring	1 & 2	298735-3	Figure 51 Page 90

Parts List – Recoil Cylinder Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Center Gland Ring	1 & 2	298735-4	Figure 51 Page 90
Chevron Packing Ring	1 & 2	298735-1	Figure 51 Page 90
Rear Gland Ring	1 & 2	298735-2	Figure 51 Page 90
Gland Bushing	1 & 2	298739-5	Figure 51 Page 90
Leather Washer	1 & 2	298739-6	Figure 21 Page 37
Needle Valve	1 & 2	298736-1	Figure 51 Page 90
Gland Ring	1 & 2	298732-5	Figure 21 Page 37
Packing Ring	1 & 2	298732-4
Gland Nut	1 & 2	298739-3	Figure 51 Page 90
Locking Screw	1 & 2	298739-2	Figure 51 Page 90
Plug	1 & 2	298739-7	Figure 51 Page 90
Washer	1 & 2	298739-4	Figure 51 Page 90
Locking Plate	1 & 2	298738-3	Figure 51 Page 90
Collar	1 & 2	298737-1	Figure 51 Page 90
Friction Disc	1 & 2	298732-3

Parts List – Loader Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Loader Assembly	1	298742	Figure 16 Page 30
Loader Assembly	2	298847
Base	1	298741-1	323891-1	Figure 16 Page 30
Base	2	298838-1	324104-1
Left Frame	1	298763-1	323894-1	Figure 16 Page 30
Left Frame	2	298842-1	324104-6
Right Frame	1	298764-1	323895-1	Figure 16 Page 30
Right Frame	2	298843-1	324104-5
Front Guide	1 & 2	298766-1	Figure 16 Page 30
Screw	1 & 2	298776-3
Rear Guide	1	298767-1	Figure 16 Page 30
Rear Guide	2	298844-1
Rail, R.H.	1	298778-1	Figure 16 Page 30
Rail, L.H.	2	298851-1
Rail, L.H.	1	298780-1	Figure 16 Page 30
Rail, R.H.	2	298852-1
Screw	1 & 2	298776-2

Parts List – Loader Assembly

Name	Mark	Ordnance Mod. 0	Number Mod. 1	Reference
Compression Rail, L.H.	1	298782-1	Figure 16 Page 30
Compression Rail, R.H.	2	298853-1
Ammunition Clip Guide	1	298769-2	Figure 16 Page 30
Ammunition Clip Guide	2	298854-1
Crosspiece	1 & 2	298769-1	323898-1	Figure 18 Page 32
Cover	1 & 2	298769-3	Figure 18 Page 32
Star Wheel Plunger	1 & 2	298777-1	323900-1	Figure 20 Page 35
Plunger Spring	1 & 2	298777-2	Figure 20 Page 35
Spring Seat	1 & 2	298777-3	323900-2	Figure 20 Page 35
Rocker Arm	1 & 2	298746-1	323892-1	Figure 20 Page 35
Bearing Pin	1 & 2	298748-7	Figure 20 Page 35
Adjusting Screw	1 & 2	298748-6
Tray Catch Lever	1 & 2	298747-1	323893-1	Figure 20 Page 35
Plunger	1 & 2	298748-2	Figure 20 Page 35
Loader Catch Lever	1	298749-4	Figure 20 Page 35
Loader Catch Lever	2	298839-2
Trigger Catch Lever	1	298747-4	323893-4	Figure 20 Page 35

Parts List – Loader Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Trigger Catch Lever	2	298839-1	324104-2 Figure 20
Bearing Pin	1 & 2	298748-1	Page 35 Figure 20
Plunger	1 & 2	298748-4	Page 35 Figure 20
Plunger Spring	1 & 2	298748-5	Page 35 Figure 20
Rammer Control Spindle	1 & 2	298750-1	323892-5	Page 35 Figure 20
Arm	1	298750-2	323892-6	Page 35
Arm	2	298840-4	324104-4 Figure 20
Fixed Tappet	1	298749-2	323892-4	Page 35
Fixed Tappet	2	298840-1	324104-3 Figure 20
Free Tappet	1	298749-3	Page 35
Free Tappet	2	298840-2 Figure 20
Spring	1	298749-1	Page 35
Spring	2	298840-3 Figure 20
Collar	1 & 2	298748-8	Page 35 Figure 20
Rammer Cocking Lever, L.H.	1	298769-4	Page 35
Rammer Cocking Lever, L.H.	2	298841-4 Figure 20
Rammer Cocking Lever, R.H.	1	298751-3	Page 35

Parts List – Loader Assembly

Name	Mark	Ordinance Number		Reference
		Mod. 0	Mod. 1	
Rammer Cocking Lever, R.H.	2	298841-2 Figure 20
Shaft	1	298751-1	Page 35
Shaft	2	298854-3 Figure 23
Shaft Arm	1	298751-2	Page 42
Shaft Arm	2	298854-2 Figure 23
Pin	1 & 2	298748-9	Page 42
Catch Release Link	1 & 2	298746-3	323892-2	Figure 23 Page 42
Catch Release Spindle	1 & 2	298746-4	Figure 20 Page 35
Spindle Arm	1 & 2	298752-3	Figure 20 Page 35
Clevis Pin	1 & 2	298746-5	323892-3	Figure 20 Page 35
Catch Release Lever	1 & 2	298752-2	Figure 20 Page 35
Catch Release Piston	1 & 2	298752-1	Figure 20 Page 35
Catch Mechanism Spindle	1 & 2	298753-2	323893-5	Figure 20 Page 35
Catch Arm, L.H.	1 & 2	298747-3	323893-3	Figure 20 Page 35
Catch Arm, R.H.	1 & 2	298747-2	323893-2	Figure 20 Page 35
Spring, L.H.	1 & 2	298746-2	Figure 20 Page 35
Spring, R.H.	1 & 2	298753-1	Figure 20 Page 35

Parts List – Loader Assembly

Name	Mark	Ordinance Number		Reference
		Mod. 0	Mod. 1	
Catch Head, L.H.	1 & 2	298787-1	323898-4	Figure 20 Page 35
Catch Head, R.H.	1 & 2	298786-1	323898-3	Figure 65 Page 101
Pawl	1 & 2	298785-1	323900-3	Figure 65 Page 101
Bearing Pin	1 & 2	298785-3	323900-4	Figure 65 Page 101
Plunger	1 & 2	298785-5	Figure 65 Page 101
Spring	1 & 2	298785-2	Figure 65 Page 101
Catch Head Bracket	1 & 2	298785-4	323900-5	Figure 16 Page 30
Screw	1 & 2	298785-6	323900-6	Figure 16 Page 30
Beveled Block, L.H.	1 & 2	298768-3	323897-3
Beveled Block, R.H.	1 & 2	298768-4	323897-4
Feed Control Spindle	1 & 2	298784-3	323893-6	Figure 20 Page 35
Feed Control Lever	1 & 2	298784-2	Figure 20 Page 35
Spindle Arm	1 & 2	298753-3	Figure 20 Page 35
Retaining Screw	1 & 2	298776-9
Feed Control Rod	1 & 2	298776-8	Figure 20 Page 35
Rod End	1 & 2	298777-4	Figure 20 Page 35
Intermediate Control Spindle	1 & 2	298750-3	Figure 20 Page 35

Parts List – Loader Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Inner Arm	1	298750-4	Figure 20 Page 35
Inner Arm	2	298841-3
Outer Arm	1	298752-4	Figure 20 Page 35
Outer Arm	2	298841-1
Clevis Pin	1 & 2	298748-3	Figure 20 Page 35
Star Wheel, and Journal, L.H.	1 & 2	298770-1 & 298775-1	Figure 20 Page 35
Star Wheel, and Journal, R.H.	1 & 2	298770-1 & 298772-1	Figure 20 Page 35
Note—A Star Wheel and its Journal should be replaced as a unit.				
Shaft, L.H.	1 & 2	298774-1	323899-2	Figure 20 Page 35
Shaft, R.H.	1 & 2	298771-1	323899-1	Figure 20 Page 35
Bushing	1 & 2	298773-4	323897-5
Extension Piece	1 & 2	298773-3
Rivet	1 & 2	298773-2
Screw	1 & 2	298776-1	323897-6	Figure 62 Page 99
Star Wheel Support, L.H.	1 & 2	298768-2	323897-2	Figure 20 Page 35
Star Wheel Support, R.H.	1 & 2	298768-1	323897-1	Figure 20 Page 35
Stop Pawl Holder, L.H.	1 & 2	298756-1	Figure 17 Page 31

Parts List – Loader Assembly

Name	Mark	Ordinance Number		Reference
		Mod. 0	Mod. 1	
Stop Pawl Holder, R.H.	1 & 2	298754-1	Figure 17 Page 31
Stop Pawl	1 & 2	298754-5	Figure 17 Page 31
Feed Rod, L.H.	1 & 2	298757-1	Figure 17 Page 31
Feed Rod, R.H.	1 & 2	298761-2
Feed Pawl Holder, L.H.	1 & 2	298757-2	Figure 17 Page 31
Feed Pawl Holder, R.H.	1 & 2	298761-1
Feed Pawl, L.H.	1 & 2	298762-1	Figure 69 Page 107
Feed Pawl, R.H.	1 & 2	298758-1
Bearing Pin	1 & 2	298754-4	Figure 69 Page 107
Bushing	1 & 2	298754-3	Figure 69 Page 107
Pawl Spring	1 & 2	298754-2	Figure 69 Page 107
Plunger	1 & 2	298759-3	Figure 17 Page 31
Plunger Spring	1 & 2	298759-1	Figure 17 Page 31
Roller	1 & 2	298776-6
Retaining Screw	1 & 2	298759-2
Rammer Tray Assembly	1 & 2	298788	Figure 19 Page 33
Rammer Tray	1 & 2	298789-1	Figure 19 Page 33

Parts List – Loader Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Tray Pawl, L.H.	1 & 2	298791-1	Figure 57 Page 94
Tray Pawl, R.H.	1 & 2	298791-4	Figure 57 Page 94
Bearing Pin	1 & 2	298791-8	Figure 57 Page 94
Plunger	1 & 2	298791-3	Figure 57 Page 94
Plunger Spring	1 & 2	298791-2	Figure 57 Page 94
Rammer Assembly	1 & 2	298793	Figure 19 Page 33
Rammer Rod	1 & 2	298793-3	Figure 19 Page 33
Rammer Spring	1 & 2	298793-1	Figure 19 Page 33
Spring Seat	1 & 2	298793-5	Figure 19 Page 33
Locking Screw	1 & 2	298793-4	Figure 19 Page 33
Rammer Head	1 & 2	298793-2	Figure 19 Page 33
Nut	1 & 2	298791-7	Figure 19 Page 33
Rammer Buffer	1 & 2	298792	323903-3	Figure 19 Page 33
Rammer Shoe	1 & 2	298794-1	Figure 19 Page 33
Rammer Lever, L.H.	1 & 2	298795-2	Figure 19 Page 33
Rammer Lever, R.H.	1 & 2	298795-1	Figure 19 Page 33
Bearing Screw	1 & 2	298791-9	Figure 58 Page 95

Parts List – Loader Assembly

Name	Mark	Ordnance Mod. 0	Number Mod. 1	Reference
Plunger	1 & 2	298791-6	Figure 59 Page 95
Plunger Spring	1 & 2	298791-5	Figure 59 Page 95
Housing Assembly				
Housing Assembly	1	298667	Figure 13 Page 27
Housing Assembly	2	298811
Housing	1	298798	Figure 13 Page 27
Housing	2	298801
Barrel Stop	1 & 2	298673-2	323875-3	Figure 13 Page 27
Screw	1 & 2	298672-7	Figure 13 Page 27
Barrel Lock	1	298673-1	323874-2	Figure 13 Page 27
Barrel Lock	2	298813-1	324100-2
Safety Catch Arm	1 & 2	298671-2	323874-1	Figure 13 Page 27
Safety Plunger	1 & 2	298676-5	Figure 13 Page 27
Spring	1 & 2	298676-3	Figure 13 Page 27
Spring Seat	1 & 2	298676-1	Figure 13 Page 27
Tray Bolt	1 & 2	298676-2	Figure 13 Page 27
Sleeve	1 & 2	298676-4	Figure 13 Page 27

Parts List – Housing Assembly

Name	Mark	Ordnance Mod. 0	Number Mod. 1	Reference
Spring	1 & 2	298676-6	Figure 13 Page 27
Spring Seat	1 & 2	298676-7	Figure 13 Page 27
Extractor, L.H.	1 & 2	298674-2	323874-4	Figure 13 Page 27
Extractor, R.H.	1 & 2	298674-1	323874-3	Figure 13 Page 27
Note—Extractors should always be replaced in pairs.				
Extractor Spindle	1	298674-3	Figure 13 Page 27
Extractor Spindle	2	298815-2
Bushing	1 & 2	298674-4
Spindle Arm	1	298675-1	Figure 13 Page 27
Spindle Arm	2	298815-1
Crankshaft Bushing	1 & 2	298672-8	Figure 13 Page 27
Locking Screw	1 & 2	298672-2	Figure 13 Page 27
Crankshaft	1	298686
Crankshaft	2	298820
Shaft	1 & 2	298687-2	Figure 13 Page 27
Outer Crank	1	298687-1	Figure 13 Page 27
Outer Crank	2	298821-1

Parts List – Housing Assembly

Name	Mark	Ordinance Number		Reference
		Mod. 0	Mod. 1	
Lock Pin	1 & 2	298681-3
Elastic Stop Nut	1 & 2	299210-1
Roller	1 & 2	298672-3	Figure 13 Page 27
Washer	1 & 2	298672-4	Figure 13 Page 27
Screw	1 & 2	298672-7	Figure 13 Page 27
Left Inner Crank	1 & 2	298683-1	Figure 13 Page 27
Right Inner Crank	1 & 2	298683-2	Figure 13 Page 27
Note—Inner cranks should always be replaced in pairs.				
Closing Spring Assembly	1	298684	Figure 13 Page 27
Closing Spring Assembly	2	298816
Case	1	298685-4	Figure 13 Page 27
Case	2	298819-1
Spring	1	298685-1	Figure 13 Page 27
Spring	2	298818-1
Cover	1	298685-3	Figure 13 Page 27
Cover	2	298817-1

Parts List – Housing Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Breech Block Assembly	1 & 2	298677	Figure 15 Page 29
Breech Block	1 & 2	298678-1	Figure 13 Page 27
Sear	1 & 2	298680-1	Figure 15 Page 29
Sear Spring	1 & 2	298681-2	Figure 15 Page 29
Inner Cocking Lever	1 & 2	298682-4	Figure 15 Page 29
Outer Cocking Lever	1 & 2	298680-2	Figure 15 Page 29
Firing Pin	1 & 2	298682-3	Figure 15 Page 29
Firing Spring	1 & 2	298681-1	Figure 15 Page 29
Firing Hole Bushing	1 & 2	298682-2	Figure 15 Page 29
Locking Pin	1 & 2	298681-4	Figure 15 Page 29
Firing Spring Cover	1 & 2	298682-1	Figure 15 Page 29

Slide Assembly

Slide Assembly	1 & 2	298688	Figure 2 Page 17
Slide	1	298689	Figure 2 Page 17
Slide	2	298822	Figure 2 Page 17
Slide Key	1 & 2	298855-1	Figure 85 Page 126
Slide Bolt	1 & 2	298855-4	Figure 85 Page 126

Parts List – Slide Assembly

Name	Mark	Ordinance Number Mod. 0	Number Mod. 1	Reference
Lock Washer	1 & 2	298855-2	Figure 85 Page 126
Lock Washer	1 & 2	298855-3	Figure 85 Page 126
Depression Bumper Bracket	1 & 2	298989-1	Figure 2 Page 17
Top Door Assembly	1	298994	Figure 79 Page 120
Top Door Assembly	2	298859	Figure 2 Page 17
Top Door	1	298700-2	Figure 79 Page 120
Top Door	2	298825-1	Figure 2 Page 17
Locking Catch Bracket	1 & 2	298710-4	Figure 79 Page 120
Locking Catch Spring	1 & 2	298699-3	Figure 79 Page 120
Locking Catch	1 & 2	298699-2	323880-1	Figure 79 Page 120
Pivot Pin	1 & 2	298703-4	323881-4	Figure 79 Page 120
Hinge	1 & 2	298699-1	Figure 79 Page 120
Hinge Pin	1 & 2	298699-4	Figure 79 Page 120
Bottom Cover	1	298705-1	323880-2	Figure 82 Page 123
Bottom Cover	2	298828-1	324101-3	Figure 2 Page 17
Catch Assembly	1 & 2	298807-1	Figure 79 Page 120
Lever	1 & 2	298713-4	Figure 82 Page 123

Parts List – Slide Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Spring	1 & 2	298701-4	Figure 79 Page 120
Plunger	1 & 2	298701-2	Figure 79 Page 120
Knurled Head	1 & 2	298701-3	Figure 79 Page 120
Arm	1 & 2	298701-1	323881-2	Figure 82 Page 123
Rear Door	1 & 2	298721-1	Figure 9 Page 23
Hinge Pin	1 & 2	298704-4	Figure 9 Page 23
Through Bolt	1 & 2	298704-5	Figure 9 Page 23
Counterweight	1	298896-2	Figure 22 Page 39
Counterweight	2	298896-1	Figure 9 Page 23
Case Deflector Assembly	1 & 2	298808	Figure 84 Page 125
Case Deflector	1 & 2	298723-1	Figure 84 Page 125
Hinge Bolt	1 & 2	298724-2	Figure 84 Page 125
Securing Pin	1 & 2	298724-1	Figure 84 Page 125
Bracket, L.H.	1 & 2	298722-1	Figure 84 Page 125
Bracket, R.H.	1 & 2	298722-2	Figure 84 Page 125
Recoil Indicator Assembly	1 & 2	298725	Figure 83 Page 125
Indicating Plate	1 & 2	298725-2	Figure 83 Page 125

Parts List – Slide Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Indicating Arm	1 & 2	298809-2	Figure 83 Page 125
Washer	1 & 2	298726-3	Figure 83 Page 125
Spring	1 & 2	298726-2	Figure 83 Page 125
Retaining Nut	1 & 2	298725-3	Figure 83 Page 125
Stud	1 & 2	298726-1	Figure 84 Page 125
Catch Bracket Assembly	1 & 2	298809-3	Figure 85 Page 126
Catch Bracket	1 & 2	298708-4	323880-3	Figure 85 Page 126
Plunger	1 & 2	298724-4	Figure 85 Page 126
Spring Seat	1 & 2	298724-3
Spring	1 & 2	298724-5
Hand Operating Lever Shaft Assembly	1	298805-1	Figure 5 Page 20
Hand Operating Lever Shaft Assembly	2	298992-1	Figure 85 Page 126
Shaft	1	298711-1	Figure 4 Page 19
Shaft	2	298830-1	Figure 85 Page 126
Arm	1	298713-1	Figure 4 Page 19
Arm	2	298833-3	Figure 85 Page 126
Bracket	1	298713-2	Figure 4 Page 19

Parts List – Slide Assembly

Name	Mark	Ordinance Mod. 0	Number Mod. 1	Reference
Bracket	2	298832-1	Figure 85 Page 126
Screw	1 & 2	298712-5	323883-2	Figure 4 Page 19
Hand Operating Lever	1 & 2	298714-1	Figure 85 Page 126
Retaining Pin	1 & 2	298712-3	Figure 4 Page 19
Hand Operating Rod	1	298712-1	Figure 4 Page 19
Hand Operating Rod	2	298831-1	Figure 85 Page 126
Front Crank	1	298712-2	Figure 86 Page 129
Front Crank	2	298833-1	Figure 85 Page 126
Clevis Pin	1 & 2	298712-4	Figure 23 Page 42
Firing Selector Lever Assembly	1	298807-2	Figure 5 Page 20
Firing Selector Lever Assembly	2	298858-2	Figure 2 Page 17
Firing Selector Lever	1 & 2	298720-9	Figure 2 Page 17
Spring	1 & 2	298701-4	Figure 79 Page 120
Plunger	1 & 2	298701-2	Figure 79 Page 120
Knurled Head	1 & 2	298701-3	Figure 79 Page 120
Cam	1	298708-3	323881-6	Figure 4 Page 19
Cam	2	298833-2	324101-5	Figure 85 Page 126

Parts List – Slide Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Firing Rod	1 & 2	298720-1	Figure 85 Page 126
Rod End	1 & 2	298720-2	Figure 4 Page 19
Trunnion Assembly	1	298809-1	Figure 3 Page 18
Trunnion Assembly	2	298992-3	Figure 3 Page 18
Trunnion	1	298709-1	Figure 74 Page 115
Trunnion	2	298829-1	Figure 2 Page 17
Shim	1 & 2	298704-8	Figure 3 Page 18
Crank	1 & 2	298710-1	Figure 3 Page 18
Pivot Pin	1 & 2	298710-2	Figure 3 Page 18
Clevis Pin	1 & 2	298720-6	Figure 86 Page 129
Firing Plunger	1	298697-1	Figure 3 Page 18
Firing Plunger	2	298831-3	Figure 3 Page 18
Firing Lever Assembly	1	298803-1	Figure 4 Page 19
Firing Lever Assembly	2	298991-1	Figure 85 Page 126
Firing Lever	1	298718-1	323884-1	Figure 4 Page 19
Firing Lever	2	298834-1	324102-4	Figure 85 Page 126
Spring	1 & 2	298719-2

Parts List – Slide Assembly

Name	Mark	Ordinance Number		Reference
		Mod. 0	Mod. 1	
Plunger	1 & 2	298704-2
Pawl	1 & 2	298717-4	323883-6	Figure 4 Page 19
Bearing Pin	1 & 2	298719-1	323885-1	Figure 4 Page 19
Connecting Screw	1 & 2	298693-5	Figure 4 Page 19
Firing Lever Spring	1 & 2	298720-5	Figure 4 Page 19
Firing Lever Pawl Stop Stud	1 & 2	298703-2	Figure 4 Page 19
Bracket	1 & 2	298708-2	Figure 4 Page 19
Bearing Pin	1 & 2	298704-3	Figure 4 Page 19
Firing Lever Spring Stud	1 & 2	298720-3	Figure 4 Page 19
Trigger Spring Stud	1 & 2	298699-6	Figure 4 Page 19
Trigger Spring	1 & 2	298727-3	Figure 4 Page 19
Trigger	1	298727-2	323886-2	Figure 4 Page 19
Trigger	2	298835-1	324102-5	Figure 85 Page 126
Bearing Pin	1 & 2	298699-5	323881-1	Figure 4 Page 19
Side Door Assembly	1	298988	Figure 81 Page 122
Side Door Assembly	2	298999	Figure 2 Page 17
Side Door	1	298702-1	323882-1	Figure 81 Page 122

Parts List – Slide Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Side Door	2	298827-1	324101-2	Figure 2 Page 17
Catch Bolt	1	298701-6	Figure 81 Page 122
Catch Bolt	2	298831-2
Spring	1 & 2	298701-5	Figure 81 Page 122
Indicating Screw	1 & 2	298831-4	Figure 81 Page 122
Hinge Bolt	1 & 2	298703-1	Figure 74 Page 115
Extractor Release Lever	1 & 2	298717-1	Figure 86 Page 129
Bracket	1 & 2	298717-2	Figure 86 Page 129
Bearing Screw	1 & 2	298717-3	Figure 86 Page 129
Anchor Stud	1 & 2	298698-9	Figure 86 Page 129
Spring	1 & 2	298703-3	Figure 86 Page 129
Buffer Pad	1 & 2	298720-8	Figure 85 Page 126
Retaining Screw	1 & 2	298720-7	Figure 85 Page 126
Housing Stop	1	298708-1	323881-5	Figure 74 Page 115
Housing Stop	2	298835-2	324101-4	Figure 2 Page 17
Breech Block Locking Bolt	1 & 2	298716-1	Figure 2 Page 17
Bracket	1	298715-1	323880-4	Figure 74 Page 115

Parts List – Slide Assembly

Name	Mark	Ordnance Mod. 0	Number Mod. 1	Reference
Bracket	2	298715-2	324102-3	Figure 2 Page 17
Spring	1 & 2	298712-6	323883-3	Figure 74 Page 115
Recoil Cylinder Bracket	1 & 2	298727-1	323886-2	Figure 2 Page 17
Elevating Arc, Casting	1 & 2	298728-1	Figure 2 Page 17
Elevating Arc, Weldment	1 & 2	345795	Figure 22 Page 39
Shim	1 & 2	298704-6
Dowel Pin	1 & 2	298704-9

Sight Assembly

Sight Assembly	3	299340	Figure 30 Page 53
Sight Assembly	4	299341	Figure 31 Page 54
Arm Weldment	3	299344-1	Figure 30 Page 53
Arm Weldment	4	299345-1	Figure 31 Page 54
Sight Guard Weldment	3 & 4	345493	Figure 30 Page 53
Trainer's Sight	3 & 4	299343-1	Figure 30 Page 53
Pointer's Sight	3 & 4	299343-2	Figure 30 Page 53
Front Sight	3 & 4	299342-1	Figure 30 Page 53
Adjusting Collar	3 & 4	299346-2	Figure 31 Page 54

Parts List – Sight Assembly

Name	Mark	Ordnance Number		Reference
		Mod. 0	Mod. 1	
Front Sight Bracket	3 & 4	299346-3	Figure 30 Page 53
Ferrule	3 & 4	299349-4	Figure 30 Page 53
Bar	3 & 4	299350-1	Figure 30 Page 53
Key	3 & 4	299346-1
Rear Sight	3 & 4	299349-2	Figure 30 Page 53
Expansion Plug	3 & 4	345897-259	Figure 31 Page 54
Cap	3 & 4	299350-2	Figure 30 Page 53
Dowel Pin	3 & 4	299277-4

Chapter XI

APPENDIX

A. DATA SHEET

40MM Machine Gun Mechanism

Type of mechanism recoil-operated
Type of breech block vertical sliding wedge
Brake load 4,800 pounds
Length of recoil at 0° elevation approx. 7.5 to 8.0 inches
Rate of fire 130 to 150 rounds per minute

Gun Barrel

Bore diameter in inches 1.573 inches
Length in inches (overall) 88.583 inches
Length in calibers 56
Depth of grooves0225 inches
Twist of rifling increasing from one turn in
45 calibers at origin to one
turn in 30 calibers at muzzle.

Interior Ballistics

Chamber capacity 28.3 cu. inches
Travel of projectile 78.28 inches
Muzzle velocity 2,890 ft. per second
Service pressure (maximum) 19.5 tons per sq. inch

Recoil Cylinder

Type Hydraulic
Kind of liquid (O.S. 1324) 60% glycerin, 40% water

Ammunition

Type Fixed
Weight of one complete round (brass case) 4.75 pounds
Weight of projectile, loaded and fused 1.97 pounds
Weight of one assembled clip of four (4) rounds 20 pounds

Weights

Twin mechanism with barrels and sight Mark 3	2300 pounds
Barrel assembly (including flash hider, water jacket, and recoil spring)	330 pounds
Gun Barrel only	200 pounds
Recoiling parts	490 pounds
Housing Assembly	130 pounds
Loader, complete with tray	210 pounds
Slide (twin) with elevating arc attached	800 pounds
Sight Mark 3 (for twin mount)	70 pounds
Sight Mark 4 (for quadruple mount)	90 pounds

B. LUBRICATION INSTRUCTIONS**1. Lubricants and Compounds Used:****a. Oil:**

- (1) Oil, Lubricating, Preservative, Light, O.S. 1362.

b. Grease:

- (1) Bearing Grease for General Use in Naval Ordnance, O.S. 1350.

c. Cleaning Solvents:

- (1) Diesel Fuel Oil, 7-0-2 (INT)
- (2) Solvent (commercially known as Stoddard Solvent) P-S-661
- (3) Kerosene—Water white 14-K-1
- (4) Kerosene—VV-K-211

2. Daily

Oil the gun bore. Remove and disassemble the breech block, clean the parts, and coat with light film of oil. Clean and oil the inner cranks. Clean and oil the breech block guides in the housing.

3. After Firing

As soon as practicable after firing, depress the gun, clean, dry and coat the bore with a film of oil. Oil the breech mechanism in accordance with the daily schedule.

4. Weekly

Also, if the gun gets wet or dirty, or if there is any reason to expect corrosion to start.

- a. **Loader:** Remove the loader and the rammer tray from the slide, and oil all loader sliding surfaces, springs and bearings. Use lubricant sparingly and exercise parts after lubricating. Coat all unpainted surfaces with a light film of oil or grease. Oil all working parts of the tray and coat all surfaces with a light film of oil or grease.
- b. **Housing:** Remove and disassemble the housing. Clean all parts except the closing spring assembly with solvent, and coat all surfaces with a light film of oil. The breech block closing spring assembly is packed with grease and need not be disassembled. Use lubricant sparingly.
- c. **Slide:** Oil all working parts. Apply a light film of oil or grease to all unpainted surfaces. Apply one shot with pressure gun at each of the six grease fittings after reassembly of mechanism.
- d. **Barrel:** Clean, dry and coat the gun bore with light film of oil. Clean the barrel threads and coat with film of grease. Coat the outside surfaces of the water jacket and the recoil spring with a film of grease.

The following parts, if disassembled for repairs, should be repacked with grease at assembly:

- Breech block closing spring
- Feed rod plunger spring
- Rammer spring
- Rammer lever plunger spring
- Star wheel journals, plungers and springs
- Hand operating lever catches on slide
- Trunnion bearings

C. FILLING THE RECOIL CYLINDER

To fill the recoil cylinder, elevate the gun to about twenty-five degrees, remove the fill plug, and unscrew the needle valve several turns. Using the filling funnel, pour the liquid in slowly until it overflows. Replace the plug and elevate and depress the gun slowly several times, returning the gun to

about twenty-five degrees elevation. Remove the fill plug, and using the funnel, pour in liquid until it again overflows. Replace the fill plug and reset the needle valve by closing it and then unscrewing it one-third of a turn. Approximately 1.2 pints of liquid is required to fill the recoil cylinder.

D. VARIATIONS

1. Elevating Arc

Elevating arcs have been manufactured by two different methods. Elevating arc (298728-1) is a casting, while elevating arc (345795) is a weldment.

2. Breech Block

In breech blocks of earlier manufacture, the firing hole bushing (298682-2) is threaded, and installed in the breech block by the use of the wrench (298869-6), and locked in place by the use of the locking pin (298681-2).

In later breech blocks, the firing hole bushing is an integral part of the breech block.

3. Loader

In loaders of later manufacture, no feed control thumb lever (298784-1) will be found. Consequently the instructions in Chapter VI to place this lever on the red arrow position are to be disregarded in operating these mechanisms.

DISTRIBUTION

Requests for copies of Ordnance Pamphlet No. 820 should be addressed to the nearest BuOrd Publications Distribution Center:

Commandant and Superintendent
U. S. Naval Gun Factory, Navy Yard
Washington 25, D. C.

Commandant
Navy Yard
Mare Island, California

Officer in Charge
Ordnance Publications Subcenter
Naval Supply Depot
Pearl Harbor, T. H.

Commander Service Force, Seventh Fleet
Ordnance Publications Subcenter
c/o Fleet Post Office
San Francisco, California

DISTRIBUTION:

Standard Navy Distribution List No. 15
2 copies each unless otherwise noted.

1. (1 copy), α-h, j-n, q-t, x, z-ff, ii-ll, nn, oo, qq, ss-zz; 2. (1 copy), α, d-h, n-p, s, t, v, bb, dd, gg; 3. α*, e*, f*, i*, j*, k*, l*, r*, t*, x*, bb*, dd*, hh*, jj*, kk*, qq*, xx*, zz*, ααα*, ddd*, eee*; 4. α*, b*, e*, f*, g, i*, j*, k*, l*, r*, t*, x*, bb*, dd*, kk*, qq*, tt*, uu*, vv, xx, yy*; 6. (3 copies), α-p; 7. α-c, f-i, j, l (Des Bases only), o, x, y, αα; 8. h (NOL and No. Beach only), i, j, n (SPECIAL LIST K, L, O, S, V, Z, AA), q, r, u, gg; 8. (3 copies), x; 10. s, t; 11. α (Vice CNO, SecNav, ComdtMarCorps); 12.; 14. α.

* Applicable Ships.

